
# FusionServer 2288H V5 Server

# **Technical White Paper**

Issue 13

**Date** 2023-11-30



#### Copyright © xFusion Digital Technologies Co., Ltd. 2023. All rights reserved.

No part of this document may be reproduced or transmitted in any form or by any means without prior written consent of xFusion Digital Technologies Co., Ltd.

#### **Trademarks and Permissions**

**CFUSION** and other xFusion trademarks are trademarks of xFusion Digital Technologies Co., Ltd. All other trademarks and trade names mentioned in this document are the property of their respective holders.

#### **Notice**

In this document, "xFusion" is used to refer to "xFusion Digital Technologies Co., Ltd." for concise description and easy understanding, which does not mean that "xFusion" may have any other meaning. Any "xFusion" mentioned or described hereof may not be understood as any meaning other than "xFusion Digital Technologies Co., Ltd.", and xFusion Digital Technologies Co., Ltd. shall not bear any liability resulting from the use of "xFusion".

The purchased products, services and features are stipulated by the contract made between xFusion and the customer. All or part of the products, services and features described in this document may not be within the purchase scope or the usage scope. Unless otherwise specified in the contract, all statements, information, and recommendations in this document are provided "AS IS" without warranties, guarantees or representations of any kind, either express or implied.

The information in this document is subject to change without notice. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information, and recommendations in this document do not constitute a warranty of any kind, express or implied.

# xFusion Digital Technologies Co., Ltd.

Address: 9th Floor, Building 1, Zensun Boya Square, Longzihu Wisdom Island

Zhengdong New District 450046 Zhengzhou, Henan Province People's Republic of China

Website: https://www.xfusion.com

# **About This Document**

# **Purpose**

This document describes the FusionServer 2288H V5 rack server in terms of features, structure, specifications, and component hardware and software compatibility.

#### **Intended Audience**

This document is intended for pre-sales engineers.

# **Symbol Conventions**

The symbols that may be found in this document are defined as follows.

Symbol	Description		
▲ DANGER	Indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.		
<b>⚠ WARNING</b>	Indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.		
<b>⚠</b> CAUTION	Indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury.		
<b>NOTICE</b>	Indicates a potentially hazardous situation which, if not avoided, could result in equipment damage, data loss, performance deterioration, or unanticipated results.		
	NOTICE is used to address practices not related to personal injury.		
NOTE	Supplements the important information in the main text.  NOTE is used to address information not related to personal injury, equipment damage, and environment deterioration.		

# **Change History**

Issue	Date	Description
13	2023-11-30	<ul> <li>Updated 10 Certifications.</li> <li>Added 11 Waste Product Recycling.</li> <li>Updated A.4 Nameplate .</li> </ul>
12	2023-08-31	<ul> <li>Updated 5.5.2 Drive Numbering.</li> <li>Updated 5.8 PSUs .</li> </ul>
11	2023-04-30	Updated 6.1 Technical Specifications.
10	2023-03-31	Updated A.3 Operating Temperature Limitations .
09	2022-12-30	Optimized 5.5.1 Drive Configuration.
08	2022-11-30	Updated A.4 Nameplate .
07	2022-11-11	Updated 5.5.1 Drive Configuration and 5.5.2 Drive Numbering.
		Updated 6.3 Physical Specifications .
		Updated 8.1 Security.
		Updated A.3 Operating Temperature     Limitations .
06	2022-08-12	Optimized 6.3 Physical Specifications .
05	2022-06-25	Added a figure that shows how to measure dimensions.
		Added the description of the enhanced management chip (VB) and normal management chip.
		Added the GPU riser card, and updated 5.7.2     PCle Slots.
		Updated 6.1 Technical Specifications and claimed support for U.2 drives.
		Updated the CE, UKCA, and CCC certification standards in 10 Certifications.
		Added A.1 Chassis Label.
		Updated A.3 Operating Temperature     Limitations .
04	2022-05-20	Added support for 8 x 3.5" drive pass-through configuration 2.
03	2022-04-22	Added support for 8 x 2.5" drive pass-through configuration 3.

Issue	Date	Description	
02	2022-03-18	<ul> <li>Added support for 8 x 3.5" drive pass-through configuration 1.</li> <li>Added Certifications [1288H V5-BP].</li> </ul>	
01	2021-12-20	This issue is the first official release.	

# **Contents**

About This Document	ii
1 Product Introduction	1
2 Features	2
3 Physical Structure	5
4 Logical Structure	
5 Hardware Description	
5.1 Front Panel	
5.1.1 Appearance	
5.1.2 Indicators and Buttons	
5.1.3 Ports	
5.2 Rear Panel	
5.2.1 Appearance	
5.2.2 Indicators	
5.2.3 Ports	21
5.3 Processor	23
5.4 Memory	23
5.4.1 DDR4 Memory	23
5.4.1.1 Memory Identifier	23
5.4.1.2 Memory Subsystem Architecture	25
5.4.1.3 Memory Compatibility	26
5.4.1.4 DIMM Installation Rules	27
5.4.1.5 Memory Installation Positions	28
5.4.1.6 Memory Protection Technologies	30
5.4.2 DCPMM	30
5.4.2.1 Memory Identifier	31
5.4.2.2 Memory Subsystem Architecture	31
5.4.2.3 Memory Compatibility	32
5.4.2.4 DIMM Installation Rules	34
5.4.2.5 Memory Installation Positions	35
5.4.2.6 Memory Protection Technologies	36
5.5 Storage	37

5.5.1 Drive Configuration	37
5.5.2 Drive Numbering	49
5.5.3 Drive Indicators	57
5.5.4 RAID Controller Card	59
5.6 Network	59
5.6.1 LOMs	59
5.6.2 FlexIO Cards	62
5.7 I/O Expansion	66
5.7.1 PCIe Cards	66
5.7.2 PCIe Slots	66
5.7.3 PCIe Slot Description	70
5.8 PSUs	73
5.9 Fans	74
5.10 Boards	75
5.10.1 Mainboard	75
5.10.2 Drive Backplane	78
6 Product Specifications	85
6.1 Technical Specifications	
6.2 Environmental Specifications	
6.3 Physical Specifications	
7 Software and Hardware Compatibility	
8 Safety Instructions	
8.1 Security	
8.2 Maintenance and Warranty	99
9 System Management	100
10 Certifications	102
11 Waste Product Recycling	104
A Appendix	105
A.1 Chassis Label	
A.1.1 On the Front Top.	
A.1.1 Nameplate	
A.1.1.2 Certificate	
A.1.1.3 Sample Quick Access Tags	
A.1.2 Chassis Tail Label	
A.1.3 Chassis Internal Label	
A.2 Product SN	
A.3 Operating Temperature Limitations	
A.4 Nameplate	
A.5 RAS Features.	
A.6 Sensor List	

B Glossary	124
B.1 A-E	124
B.2 F-J	124
B.3 K-O	125
B.4 P-T	125
B.5 U-Z	126
C Acronyms and Abbreviations	127
C.1 A-E	
C.2 F-J	128
C.3 K-O	130
C.4 P-T	130
C.5 U-Z	

# Product Introduction

FusionServer 2288H V5 (2288H V5) is a new-generation 2U 2-socket rack server designed for Internet, Internet Data Center (IDC), cloud computing, enterprise, and telecom applications.

The 2288H V5 is ideal for IT core services, cloud computing, high-performance computing, distributed storage, big data processing, enterprise or telecom applications, and other complex workloads.

The reliable 2288H V5 features low power consumption, high scalability, easy deployment, and simplified management.

#### **◯** NOTE

For details about the 2288H V5 nameplate information, see  ${\bf A.4~Nameplate}$  .





# **2** Features

#### **Performance and Scalability**

- Powered by two Intel<sup>®</sup> Xeon<sup>®</sup> Scalable Skylake or Cascade Lake processors, the server provides up to 28 cores, 3.8 GHz frequency, a 38.5 MB L3 cache, and two 10.4 GT/s UPI links between the processors, which deliver supreme processing performance.
  - It supports up to two processors with 56 cores and 112 threads to maximize the concurrent execution of multithreaded applications.
  - An L2 cache is added. Each core can exclusively use 1 MB of L2 cache and at least 1.375 MB of L3 cache.
  - Intel Turbo Boost Technology 2.0 allows processor cores to run faster than the frequency specified in the Thermal Design Power (TDP) configuration if they are operating below power, current, and temperature specification limits.
  - Intel Hyper-Threading Technology enables each processor core to run up to two threads, improving parallel computation capability.
  - The hardware-assisted Intel® Virtualization Technology (Intel® VT) allows operating system (OS) vendors to better use hardware to address virtualization workloads.
  - Intel® Advanced Vector Extensions 512 (Intel AVX-512) significantly accelerates floating-point performance for computing-intensive applications.
  - The Cascade Lake processors support Intel® Deep Learning Boost vector neural network instructions (VNNI) to improve the performance of deep learning applications.
- The server supports double data rate 4 (DDR4) registered dual in-line memory modules (RDIMMs) and load-reduced DIMMs (LRDIMMs) with error checking and correcting (ECC). A server fully configured with twenty-four 2933 MT/s memory modules (only available with Cascade Lake processors) provides 3072 GB memory space and the maximum theoretical memory bandwidth of 249.9375 GB/s.
- A server supports a maximum of 12 Intel<sup>®</sup> Optane<sup>TM</sup> DC persistent memory modules (DCPMMs for short). When the DDR4 memory modules are used together, the server supports a maximum of 7.5 TB memory capacity (calculated based on a maximum of 128 GB capacity per DDR4 memory module and a maximum of 512 GB capacity per DCPMM).

- Flexible drive configurations cater to a variety of business requirements and ensure high elasticity and scalability of storage resources.
- The use of all solid-state drives (SSDs) is supported. An SSD supports up to 100 times more I/O operations per second (IOPS) than a typical hard disk drive (HDD). The use of all SSDs provides higher I/O performance than the use of all HDDs or a combination of HDDs and SSDs.
- The LANs on motherboard (LOMs) and FlexIO cards provide a variety of ports to meet different networking requirements.
- With Intel integrated I/O, the Intel<sup>®</sup> Xeon<sup>®</sup> Scalable processors integrate the PCIe 3.0 controller to shortens I/O latency and improve overall system performance.
- The server supports up to eight PCle 3.0 slots.

#### **Availability and Serviceability**

- Carrier-class components with process expertise ensure high system reliability and availability.
- The server uses hot-swappable SAS/SATA/NVMe drives. It supports RAID 0, 1, 1E, 10, 5, 50, 6, and 60, depending on the RAID controller card used. It also uses a supercapacitor to protect the RAID cache data against power failures.
- The SSDs offer better reliability than HDDs, ensuring continued system performance.
- The server provides simplified O&M and efficient troubleshooting through the UID/HLY LED indicators on the front panel, fault diagnosis LED, and iBMC WebI II
- The iBMC monitors system parameters in real time, triggers alarms, and performs recovery actions in case of failures, minimizing system downtime.
- For more information about the warranty in the Chinese market, see Warranty.

#### Manageability and Security

- The built-in iBMC monitors server operating status and provides remote management.
- A password is required for accessing the BIOS, ensuring system boot and management security.
- The Network Controller Sideband Interface (NC-SI) allows a network port to serve as a management port and a service port for maximized return on investment (ROI) for customers. The NC-SI feature is disabled by default and can be enabled through the iBMC or BIOS.
- The integrated Unified Extensible Firmware Interface (UEFI) improves setup, configuration, and update efficiency and simplifies fault handling.
- Lockable server chassis panel ensures security of local data.
- The Advanced Encryption Standard–New Instruction (AES NI) algorithm allows faster and stronger encryption.
- Intel Execute Disable Bit (EDB) function prevents certain types of malicious buffer overflow attacks when working with a supported OS.
- Intel Trusted Execution Technology enhances security using hardware-based defense against malicious software attacks, allowing applications to run independently.

- The trusted platform module (TPM) and trusted cryptography module (TCM) provide advanced encryption functions, such as digital signatures and remote authentication.
- The following requirements in NIST SP 800-147B are met:
  - The BIOS firmware digital signature update mechanism is supported. During the upgrade, the digital signature is verified to prevent unauthorized BIOS firmware upgrade.
  - The flash security protection mechanism is supported to prevent unauthorized modification of the flash memory in the OS.

#### **◯** NOTE

The service port with NC-SI enabled supports the following configuration:

- Configuring any port on the FlexIO card or PCle NIC as the service port with NC-SI enabled. Host port 1 is configured by default.
- Enabling, disabling, and setting a virtual local area network (VLAN) ID for this port. The VLAN ID is 0 and disabled by default.
- Configuring IPv4 addresses (IPv4 address, subnet mask, and gateway) and IPv6 addresses (IPv6 address, prefix length, and gateway) for this port.

#### **Energy Efficiency**

- The 80 Plus Platinum power supply units (PSUs) of multiple power ratings provide 94% power efficiency at 50% load.
- The server supports active/standby power supplies and high-voltage DC (HVDC) for improved power supply efficiency.
- Efficient voltage regulator-down (VRD) power supplies for boards minimize the energy loss from DC/DC power conversion.
- Area-based, Proportional-Integral-Derivative (PID) intelligent fan speed adjustment and intelligent CPU frequency scaling optimize heat dissipation and reduce overall system power consumption.
- The improved thermal design with energy-efficient fans ensures optimal heat dissipation and reduces system power consumption.
- The server is protected with power capping and power control measures.
- Staggered spin-up for drives reduces the server boot power consumption.
- Intel® Intelligent Power Capability allows a processor to be powered on or off based on requirements.
- Low-voltage Intel<sup>®</sup> Xeon<sup>®</sup> Scalable processors consume less energy, ideally suited for data centers and telecommunications environments constrained by power and thermal limitations.
- SSDs consume 80% less power than HDDs.

# 3 Physical Structure


Figure 3-1 2288H V5 physical structure (example: 12 x 3.5" drives)

1	I/O module 1	2	I/O module 2
3	Power supply unit (PSU)	4	I/O module 3
5	Chassis	6	(Optional) built-in drive module <sup>a</sup>
7	Supercapacitor holder	8	(Optional) air duct <sup>a</sup>
9	Front drive backplane	10	Fan module bracket
11	Fan modules	12	Front drive

13	FlexIO	14	Mainboard
15	RAID controller card	16	TPM/TCM
17	Memory	18	Processor
19	Heat sink	-	-
a: Install either the air duct or built-in drive module.			

# 4 Logical Structure

Figure 4-1 2288H V5 logical structure



- The server supports one or two Intel<sup>®</sup> Xeon<sup>®</sup> Scalable processors.
- The server supports up to 24 memory modules.
- The CPUs (processors) interconnect with each other through two UPI links at a speed of up to 10.4 GT/s.
- Three PCIe riser cards connect to the processors through PCIe buses to provide ease of expandability and connection.
- The RAID controller card on the mainboard connects to CPU 1 through PCIe buses, and connects to the drive backplane through SAS high-speed cables. A variety of drive backplanes are provided to support different local storage configurations.
- The LBG-2 Platform Controller Hub (PCH) supports:
  - Two 10GE optical LOM ports or two 10GE electrical LOM ports
  - Two GE electrical LOM ports

- Uses the BMC management chip, and supports a VGA, a management network port, a debugging serial port, and other management ports.
- The BMC management chip can be an enhanced management chip (VB) or an ordinary management chip.

# 5 Hardware Description

- 5.1 Front Panel
- 5.2 Rear Panel
- 5.3 Processor
- 5.4 Memory
- 5.5 Storage
- 5.6 Network
- 5.7 I/O Expansion
- 5.8 PSUs
- 5.9 Fans
- 5.10 Boards

### **5.1 Front Panel**

# 5.1.1 Appearance

• 8 x 2.5" drive configuration

Figure 5-1 Front view



1	Drives	2	(Optional) Built-in DVD drive
3	Slide-out label plate (with an SN label)	-	-

#### • 8 x 3.5" drive configuration

Figure 5-2 Front view



1	Drives	2	Slide-out label plate (with
			an SN label)

• 12 x 3.5" drive configuration

Figure 5-3 Front view



1	Drives	2	Slide-out label plate (with
			an SN label)

• 20 x 2.5" (8 x SAS/SATA + 12 x NVMe) drive configuration

Figure 5-4 Front view



1	Drives	2	Filler module
3	Slide-out label plate (with an SN label)	-	-

• 24 x 2.5" drive configuration

Figure 5-5 Front view



1	Drives	2	Slide-out label plate (with
			an SN label)

• 25 x 2.5" drive configuration

Figure 5-6 Front view



1	Drives	2	Slide-out label plate (with
			an SN label)

#### 5.1.2 Indicators and Buttons

#### **Indicator and Button Positions**

• 8 x 2.5" drive configuration

Figure 5-7 Indicators and buttons on the front panel



1	Connection status indicator for 10GE LOM port 1	2	Connection status indicator for 10GE LOM port 2
3	Connection status indicator for GE LOM port 1	4	Connection status indicator for GE LOM port 2
5	Non-Maskable Interrupt (NMI) button	6	Fault diagnosis LED
7	Health status indicator	8	UID button/indicator
9	Power button/indicator	-	-

#### • 8 x 3.5" drive configuration

Figure 5-8 Indicators and buttons on the front panel



1	Connection status indicator for 10GE LOM port 1	2	Connection status indicator for 10GE LOM port 2
3	Connection status indicator for GE LOM port 1	4	Connection status indicator for GE LOM port 2
5	Fault diagnosis LED	6	Health status indicator
7	UID button/indicator	8	Power button/indicator

#### • 12 x 3.5" drive configuration

Figure 5-9 Indicators and buttons on the front panel



1	Connection status indicator for 10GE LOM port 1	2	Connection status indicator for 10GE LOM port 2
3	Connection status indicator for GE LOM port 1	4	Connection status indicator for GE LOM port 2
5	Fault diagnosis LED	6	Health status indicator
7	UID button/indicator	8	Power button/indicator

• 20 x 2.5" (8 x SAS/SATA + 12 x NVMe) drive configuration

Figure 5-10 Indicators and buttons on the front panel



1	Connection status indicator for 10GE LOM port 1	2	Connection status indicator for 10GE LOM port 2
3	Connection status indicator for GE LOM port 1	4	Connection status indicator for GE LOM port 2
5	Fault diagnosis LED	6	Health status indicator
7	UID button/indicator	8	Power button/indicator

• 24 x 2.5" drive configuration

Figure 5-11 Indicators and buttons on the front panel



1	Connection status indicator for 10GE LOM port 1	2	Connection status indicator for 10GE LOM port 2
3	Connection status indicator for GE LOM port 1	4	Connection status indicator for GE LOM port 2
5	Fault diagnosis LED	6	Health status indicator
7	UID button/indicator		Power button/indicator
9	NMI button	-	-

#### • 25 x 2.5" drive configuration

Figure 5-12 Indicators and buttons on the front panel



1	Connection status indicator for 10GE LOM port 1	2	Connection status indicator for 10GE LOM port 2
3	Connection status indicator for GE LOM port 1	4	Connection status indicator for GE LOM port 2
5	Fault diagnosis LED	6	Health status indicator
7	UID button/indicator	8	Power button/indicator

#### **Indicator and Button Descriptions**

**Table 5-1** Description of indicators and buttons on the front panel

Sign	Indicator and Button	Description
888	Fault diagnosis LED	<ul> <li>: The device is operating properly.</li> <li>Error code: A component is faulty.         For details about error codes, see the FusionServer Rack Server iBMC Alarm Handling.     </li> </ul>

Sign	Indicator and Button	Description
( <sup>0</sup> )	Power button/	Power indicator:
	indicator	Off: The device is not powered on.
		Steady green: The device is powered on.
		Blinking yellow: The iBMC is starting. The power button is locked and cannot be pressed. The iBMC is started in about 1 minute, and then the power indicator is steady yellow.
		Steady yellow: The device is standby.
		Power button:
		When the device is powered on, you can press this button to gracefully shut down the OS.
		NOTE For different OSs, you may need to shut down the OS as prompted.
		When the device is powered on, holding down this button for 6 seconds will forcibly power off the device.
		When the power indicator is steady yellow, you can press this button to power on the device.
<b>@</b>	UID button/ indicator	The UID button/indicator helps identify and locate a device.
		UID indicator:
		Off: The device is not being located.
		Blinking or steady blue: The device is being located.
		UID button description:
		You can control the UID indicator status by pressing the UID button or using the iBMC.
		You can press this button to turn on or off the UID indicator.
		You can press and hold down this button for 4 to 6 seconds to reset the iBMC.
(A)	Health status	Off: The device is powered off or is faulty.
	indicator	Blinking red at 1 Hz: A major alarm has been generated on the system.
		Blinking red at 5 Hz: A critical alarm has been generated on the system.
		Steady green: The device is operating properly.


Sign	Indicator and Button	Description
0	NMI button	A non-maskable interrupt (NMI) is generally triggered to stop the OS for debugging. To trigger an NMI, press this button or click the button on the iBMC WebUI.
		NOTICE
		<ul> <li>Press the NMI button only when the OS is abnormal. Do not press this button when the server is operating properly. An NMI does not gracefully shut down the OS and causes service interruption and data loss.</li> </ul>
		Before pressing the NMI button, ensure that the OS has the NMI processing program. Otherwise, the OS may crash. Exercise caution when pressing this button.
86	LOM port connection	Each indicator shows the connection status of an Ethernet LOM port.
	status indicator	Off: The network port is not in use or has failed.
		Steady green: The network port is properly connected.
		NOTE
		The indicators correspond to two 10GE and two GE network ports on the mainboard.
		The LOM has a standby power supply and will not be powered off even if the service system is powered off. As long as the LOM ports are properly connected to other working network devices, the network ports will remain connected and the indicators are on.

### **5.1.3 Ports**

#### **Port Positions**

8 x 2.5" drive configuration


Figure 5-13 Ports on the front panel



3	VGA port	-	-
---	----------	---	---


• 8 x 3.5" drive configuration

Figure 5-14 Ports on the front panel




• 12 x 3.5" drive configuration

Figure 5-15 Ports on the front panel



• 20 x 2.5" (8 x SAS/SATA + 12 x NVMe) drive configuration

Figure 5-16 Ports on the front panel



• 24 x 2.5" drive configuration


Figure 5-17 Ports on the front panel



1	USB 2.0 ports	2	USB 3.0 port
3	VGA port	-	-

• 25 x 2.5" drive configuration

Figure 5-18 Ports on the front panel



#### **Port Description**

Table 5-2 Ports on the front panel


Port	Туре	Quantity <sup>Note</sup>	Description
VGA port	DB15	1	Used to connect a display terminal, such as a monitor or KVM.
USB port	USB 2.0	2	Used to connect to a USB
	USB 3.0	1	device.  NOTICE  Before connecting an external USB device, check that the USB device functions properly. The server may operate abnormally if an abnormal USB device is connected.

Note: The number of ports varies depending on server configuration. This table lists the maximum number of ports in different configurations.

# 5.2 Rear Panel

## 5.2.1 Appearance

Figure 5-19 Rear view



1	I/O module 1	2	I/O module 2
3	I/O module 3	4	PSU 2
5	PSU 1	6	(Optional) FlexIO card


#### **◯** NOTE

- I/O modules 1, 2 and 3 can be configured with drive modules or PCle riser modules.
- The preceding figure is for reference only.

#### 5.2.2 Indicators

#### **Indicator Positions**

Figure 5-20 Indicators on the rear panel



1	LOM port indicator	2	LOM port indicator
3	Data transmission status indicator of the management network port	4	Connection status indicator of the management network port
5	UID Indicator	6	PSU indicator

### **Indicator Description**

**Table 5-3** Description of indicators on the rear panel


Indicator	Description
LOM port indicator	For details, see 5.6.1 LOMs .
PSU indicator	<ul> <li>Off: No power is supplied.</li> <li>Blinking green at 1 Hz:  — The input is normal, and the server is standby.  — The input is overvoltage or undervoltage.  — The PSU is in deep hibernation mode.</li> <li>Blinking green at 4 Hz: The firmware is being upgraded online.</li> <li>Steady green: The power input and output are normal.</li> <li>Steady orange: The input is normal, but no power output is supplied.</li> <li>NOTE  The possible causes of no power output are as follows:  • Power supply overtemperature protection  • Power output overcurrent or short-circuit  • Output overvoltage  • Short-circuit protection  • Device failure (excluding failure of all devices)</li> </ul>
Data transmission status indicator of the management network port	<ul> <li>The UID indicator helps identify and locate a device.</li> <li>Off: The device is not being located.</li> <li>Blinking or steady blue: The device is being located.</li> <li>NOTE  You can turn on or off the UID indicator by pressing the UID button or remotely running a command on the iBMC CLI.</li> <li>Off: No data is being transmitted.</li> <li>Blinking yellow: Data is being transmitted.</li> </ul>

Indicator	Description
Connection status indicator of the management network port	<ul> <li>Off: The network port is not connected.</li> <li>Steady green: The network port is properly connected.</li> </ul>

#### **5.2.3 Ports**

#### **Port Positions**

Figure 5-21 Ports on the rear panel



1	LOM port 1	2	VGA port
3	LOM port 2	4	Management network port
5	Serial port	6	USB 3.0 port
7	PSU socket	8	-

# **Port Description**

Table 5-4 Description of ports on the rear panel


Tool	Туре	Quantity	Description
LOM port 1	10GE SFP+ or 10GE BASE-T	2	10GE LOM service ports (optical/electrical). Use the optical or electrical ports based on service requirements.  For details, see 5.6.1 LOMs.

Tool	Туре	Quantity	Description
LOM port 2	1000BASE-T	2	GE LOM service ports (electrical).  For details, see <b>5.6.1 LOMs</b> .
VGA port	DB15	1	Used to connect a display terminal, such as a monitor or KVM.
Serial port	RJ45	1	Default operating system serial port used for debugging. You can also set it as the iBMC serial port by using the iBMC command.  NOTE  The port uses 3-wire serial communication interface, and the default baud rate is 115,200 bit/s.
Management network port	1000BASE-T	1	Used for server management.  NOTE  The management network port is a GE port that supports 100 Mbit/s and 1000 Mbit/s autonegotiation.
USB port	USB 3.0	2	Used to connect to a USB device.  NOTICE  Before connecting an external USB device, check that the USB device functions properly. The server may operate abnormally if an abnormal USB device is connected.
PSU socket	-	2	Used to connect to the power distribution unit (PDU) in the cabinet. You can select the number of power supply units (PSUs) as required.  NOTE  When determining the quantity of PSUs, ensure that the rated power of the PSUs is greater than that of the server.  If only one PSU is used, Predicted PSU Status cannot be set to Active/Standby on the iBMC WebUI.

#### **5.3 Processor**

- The server supports one or two processors.
- If only one processor is required, install it in socket CPU1.
- The same model of processors must be used in a server.
- Contact your local sales representative or use the Compatibility Checker to determine the components to be used.

Figure 5-22 Processor positions




# **5.4 Memory**

# 5.4.1 DDR4 Memory

#### **5.4.1.1 Memory Identifier**

You can determine the memory module properties based on the label attached to the memory module.

Figure 5-23 Memory identifier



Callout	Description	Definition
1	Capacity of the memory module	<ul> <li>8 GB</li> <li>16 GB</li> <li>32 GB</li> <li>64 GB</li> <li>128 GB</li> </ul>
2	Number of ranks of the memory module	<ul><li>1R: single-rank</li><li>2R: dual-rank</li><li>4R: quad-rank</li><li>8R: octal-rank</li></ul>
3	Data width on the DRAM	<ul><li>X4: 4-bit</li><li>X8: 8-bit</li></ul>
4	Type of the memory interface	<ul><li>PC3: DDR3</li><li>PC4: DDR4</li></ul>
5	Maximum memory speed	<ul> <li>2133 MT/S</li> <li>2400 MT/S</li> <li>2666 MT/S</li> <li>2933 MT/S</li> <li>3200 MT/S</li> </ul>
6	Column Access Strobe (CAS) latency	<ul><li>P: 15</li><li>T: 17</li></ul>
7	DIMM type	R: RDIMM     L: LRDIMM

#### **5.4.1.2 Memory Subsystem Architecture**

The 2288H V5 provides 24 memory slots. Each processor integrates six memory channels.

Install the memory modules in the primary memory channels first. If the primary memory channel is not populated, the memory modules in secondary memory channels cannot be used.

**Table 5-5** Memory channels

CPU	Memory Channel	Memory Slot
CPU 1	A (primary)	DIMM000(A)
	A	DIMM001(G)
	B (primary)	DIMM010(B)
	В	DIMM011(H)
	C (primary)	DIMM020(C)
	С	DIMM021(I)
	D (primary)	DIMM030(D)
	D	DIMM031(J)
	E (primary)	DIMM040(E)
	E	DIMM041(K)
	F (primary)	DIMM050(F)
	F	DIMM051(L)
CPU 2	A (primary)	DIMM100(A)
	A	DIMM101(G)
	B (primary)	DIMM110(B)
	В	DIMM111(H)
	C (primary)	DIMM120(C)
	С	DIMM121(I)
	D (primary)	DIMM130(D)
	D	DIMM131(J)
	E (primary)	DIMM140(E)
	Е	DIMM141(K)
	F (primary)	DIMM150(F)
	F	DIMM151(L)

#### 5.4.1.3 Memory Compatibility

Observe the following rules when configuring DDR4 DIMMs:

#### **NOTICE**

- A server must use the same model of DDR4 DIMMs, and all the DIMMs operate at the same speed, which is the smallest value of:
  - Memory speed supported by a processor
  - Maximum operating speed of a DIMM
- The DDR4 DIMMs of different types (RDIMM and LRDIMM) and specifications (capacity, bit width, rank, and height) cannot be used together.
- Contact your local sales representative or use the Compatibility Checker to determine the components to be used.
- The memory can be used with Intel® Xeon® Scalable Skylake and Cascade Lake processors. The maximum memory capacity supported varies depending on the processor model.
  - Skylake processors
    - M processors: 1.5 TB/socket
    - Other processors: 768 GB/socket
  - Cascade Lake processors
    - L processors: 4.5 TB/socket
    - M processors: 2 TB/socket
    - Other processors: 1 TB/socket
- The total memory capacity is the sum of the capacity of all DDR4 DIMMs.

#### NOTICE

- The total memory capacity cannot exceed the maximum memory capacity supported by the CPUs.
- The total memory capacity refers to the capacity when DDR4 DIMMs are fully configured. For details about the memory capacity when DCPMMs are used together with DDR4 DIMMs, see **5.4.2.3 Memory Compatibility**.
- Use the Compatibility Checker to determine the capacity type of a single memory module.
- The maximum number of DIMMs supported by a server varies depending on the CPU type, memory type, rank quantity, and operating voltage.

#### 

Each memory channel supports a maximum of 8 ranks. The number of DIMMs supported by each channel varies depending on the number of ranks supported by each channel:

Number of DIMMs supported by each channel ≤ Number of ranks supported by each memory channel/Number of ranks supported by each DIMM

• A memory channel supports more than eight ranks for LRDIMMs.

#### **◯** NOTE

A quad-rank LRDIMM generates the same electrical load as a single-rank RDIMM on a memory bus.

Table 5-6 DDR4 memory specifications

Parameter	Specifications	
Maximum capacity per DDF	128	
Rated speed (MT/s)	2933	
Operating voltage (V)	1.2	
Maximum number of DDR4	24	
Maximum DDR4 memory c	3072	
Maximum operating	1DPC <sup>c</sup>	2933 <sup>d</sup>
speed (MT/s)	2DPC	2666

- a: The maximum number of DDR4 memory modules is based on dualprocessor configuration. The value is halved for a server with only one processor.
- b: The maximum DDR4 memory capacity varies depending on the processor type. The value listed in this table is based on the assumption that DIMMs are fully configured.
- c: DPC (DIMM per channel) indicates the number of DIMMs per channel.
- d: If the Cascade Lake processor is used, the maximum operating speed of a DIMM can reach 2933 MT/s. If the Skylake processor is used, the maximum operating speed of a DIMM can reach 2666 MT/s only. Different CPUs possess different specifications, For details about the CPU parameters, see the Intel official website.
- The information listed in this table is for reference only. For details, consult the local sales representative.

#### 5.4.1.4 DIMM Installation Rules

#### **◯** NOTE

This section applies to a server fully configured with DDR4 DIMMs. If DCPMMs are used together, see **5.4.2.4 DIMM Installation Rules**.

- Observe the following when configuring DDR4 memory modules:
  - Install memory modules only when corresponding processors are installed.
  - Do not install LRDIMMs and RDIMMs in the same server.
  - Install filler memory modules in vacant slots.
- Observe the following when configuring DDR4 memory modules in specific operating mode:
  - Memory sparing mode
    - Comply with the general installation guidelines.
    - Each memory channel must have a valid online spare configuration.
    - The channels can have different online spare configurations.
    - Each populated channel must have a spare rank.
  - Memory mirroring mode
    - Comply with the general installation guidelines.
    - Each processor supports two integrated memory controllers (IMCs). At least two channels of each IMC are used for installing memory modules (channels 1 and 2, or channels 1, 2, and 3). The installed memory modules must be identical in size and organization.
    - For a multi-processor configuration, each processor must have a valid memory mirroring configuration.
  - Memory scrubbing mode
    - Comply with the general installation guidelines.

#### **5.4.1.5 Memory Installation Positions**

A 2288H V5 supports a maximum of 24 DDR4 DIMMs. To maximize the performance, balance the total memory capacity between the installed processors and load the channels similarly whenever possible.

#### NOTICE

At least one DDR4 DIMM must be installed in the memory slots corresponding to CPU 1.

Figure 5-24 Memory slots




Figure 5-25 DDR4 memory installation guidelines (1 processor)

			Number of DIMMs											
CPU	Channal	CI I DIDECT	(√: recommended °: not recommended)											
	Channel	DIMM Slot	<b>\</b>	1	1	✓	0	1	0	1	0	0	0	1
			1	2	3	4	5	6	7	8	9	10	11	12
	A	DIMM000(A)	•	•	•	•	•	•	•	•	•	•	•	•
	A	DIMM001(G)							•	•	•	•	•	•
	В	DIMM010(B)		•	•	•	•	•	•	•	•	•	•	•
		DIMM011(H)								•	•	•	•	•
	С	DIMM020(C)			•		•	•	•		•	•	•	•
CDII 1		DIMM021(I)									•		•	•
CPU 1	D	DIMM030(D)				•	•	•	•	•	•	•	•	•
	ע	DIMM031(J)								•		•	•	•
	Е	DIMM040(E)				•	•	•	•	•	•	•	•	•
	E	DIMM041(K)								•		•	•	•
	F	DIMM050(F)						•	•		•	•	•	•
	r	DIMM051(L)												•

(√: recommended ○: not recommended) CPU Channe DIMM Slot 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 DIMM001(G) . . . . . . . . . . . . . В DIMM011(H) CPU1 DIMM031(J) . . . . . . . Ε DIMM041(K) DIMM101(G) DIMM110(B) DIMM111(H) DIMM121(I) CPU2 DIMM131(J) DIMM140(E) DIMM141(K) F DIMM151(L)

Figure 5-26 DDR4 memory installation guidelines (2 processors)

## **5.4.1.6 Memory Protection Technologies**


The following memory protection technologies are supported:

- ECC
- Full mirroring
- Address range mirroring
- SDDC
- SDDC+1
- Rank sparing mode
- Static virtual lockstep
- Faulty DIMM isolation
- Memory thermal throttling
- Memory address parity protection
- Memory demand/patrol scrubbing
- Device tagging
- Data scrambling
- Adaptive double device data correction (ADDDC)
- ADDDC+1

### **5.4.2 DCPMM**

## **5.4.2.1 Memory Identifier**

Figure 5-27 Memory identifier



Callout	Description	Example
1	Component name	Intel® DCPMM
2	Serial number	8089-A2-1839-00001931
3	Model	NMA1XBD612GQS
4	Capacity	• 128 GB
		• 256 GB
		• 512 GB
5	SN QR code	8089-A2-1839-00001931

## **5.4.2.2 Memory Subsystem Architecture**

The 2288H V5 provides 24 memory slots. Each processor integrates six memory channels, and each memory channel supports up to one DCPMM.

DCPMMs must be used with DDR4 memory modules.

Table 5-7 Memory channels

СРИ	Memory Channel	Memory Slot
CPU 1	A (primary)	DIMM000(A)

CPU	Memory Channel	Memory Slot
	А	DIMM001(G)
	B (primary)	DIMM010(B)
	В	DIMM011(H)
	C (primary)	DIMM020(C)
	С	DIMM021(I)
	D (primary)	DIMM030(D)
	D	DIMM031(J)
	E (primary)	DIMM040(E)
	E	DIMM041(K)
	F (primary)	DIMM050(F)
	F	DIMM051(L)
CPU 2	A (primary)	DIMM100(A)
	А	DIMM101(G)
	B (primary)	DIMM110(B)
	В	DIMM111(H)
	C (primary)	DIMM120(C)
	С	DIMM121(I)
	D (primary)	DIMM130(D)
	D	DIMM131(J)
	E (primary)	DIMM140(E)
	Е	DIMM141(K)
	F (primary)	DIMM150(F)
	F	DIMM151(L)

## **5.4.2.3 Memory Compatibility**

Observe the following rules when configuring DC persistent memory modules (DCPMMs):

#### **NOTICE**

- The DCPMMs must be used with the DDR4 memory modules. For details, see the FusionServer PMem 200-Barlow Pass User Guide.
- Contact your local sales representative or use the Compatibility Checker to determine the components to be used.
- The memory must be used with Intel<sup>®</sup> Xeon<sup>®</sup> Scalable Cascade Lake processors. The maximum memory capacity supported varies depending on the processor model.
  - L processors: 4.5 TB/socket
  - M processors: 2 TB/socket
  - Other processors: 1 TB/socket
- The DCPMM can work only in App Direct Mode (AD) and Memory Mode (MM).
   The total supported memory capacity is calculated as follows:
  - DCPMM in AD mode
    - Total memory capacity = Total capacity of all DCPMMs + Total capacity of all DDR4 memory modules
  - DCPMM in MM mode

Total memory capacity = Total capacity of all DCPMMs (The DDR4 memory modules are used as the cache and therefore are not calculated as memory capacity.)

#### NOTICE

- The total memory capacity cannot exceed the maximum memory capacity supported by the CPUs.
- For details about the AD and MM modes, see "Operating Modes" in FusionServer PMem 200-Barlow Pass User Guide.
- Use the Compatibility Checker to determine the capacity type of a single memory module.

Table 5-8 DCPMM specifications

Item	Specifications			
Capacity per DCPMM (GB)	128	256	512	
Rated speed (MT/s)	2666	2666	2666	
Operating voltage (V)	1.2	1.2	1.2	
Maximum number of DCPMMs in a server <sup>a</sup>	12	12	12	
Maximum capacity of the server (GB) <sup>b</sup>	2304	4608	7680	

Item	Specifications				
Maximum operating speed (MT/s)	2666	2666	2666		

- a: The maximum number of DCPMMs is based on dual-processor configuration. The value is halved for a server with only one processor.
- b: The maximum memory capacity varies depending on the CPU type and DCPMM working mode. The value listed in this table is based on the assumption that 12 DCPMMs and 12 DDR4 memory modules are used with the L series CPUs and the DCPMMs work in AD mode.
- The information listed in this table is for reference only. For details, consult the local sales representative.

### 5.4.2.4 DIMM Installation Rules

- The following are general guidelines for DCPMM installation:
  - The DDR4 memory modules used with the DCPMMs include RDIMMs and LRDIMMs.
  - The DCPMMs used in a server must have the same part number (P/N code).
  - The DDR4 memory modules used with the DCPMMs in a server must have the same P/N code.
- Observe the following when configuring DCPMMs in specific operating mode:
   MM mode:

On the same server, it is recommended that the ratio of FM to NM be 2:1 to 16:1.

#### **□** NOTE

- Near memory (NM): capacity of DDR4 DIMMs used as the cache.
- Far memory (FM): capacity of the DCPMMs in MM.
- The mapping between the DCPMM and CPU is as follows:
  - DCPMMs require Cascade Lake Gold/Platinum/Silver (4215 model) CPUs.
  - Table 5-9 lists the maximum memory capacity supported by different CPUs.

**Table 5-9** Maximum memory capacity supported by a CPU

CPU Type	Maximum Memory Capacity Supported by a CPU (DDR4 and DCPMM Capacities)
Full-series	1 TB
M series	2 TB
L series	4.5 TB

## **5.4.2.5 Memory Installation Positions**

A 2288H V5 supports a maximum of 12 DCPMMs. The DCPMMs must be used with DDR4 DIMMs.

Figure 5-28 Memory slots




Figure 5-29 DCPMM and DDR4 memory configuration guidelines (1 processor)

								Configu	rations i	n Differe	ent Mode	s (●: D	DR4 DIM	M 0: D	СРММ)		
CPU	Cha	nnel	DIMM Slot	AD	MM	AD	MM	AD	MM	AD	MM						
				2-2	-2	2-2	2-1	2-	1-1	1-1	1-1						
		Α	DIMM000(A)	•			•		•		•						
		7	DIMM001(G)	0	)	(	0	(	0								
	IMC0	IMCO	IMCO	В	DIMM010(B)	•	)		•		•	•	•				
		В	DIMM011(H)	0	)	(	О										
			C	(	DIMM020(C)	•	)		•		•	Ü	)				
CPU1		C	DIMM021(I)	0	)												
CFUI	IMC1	IMC1	IMC1	IMC1	IMC1	D	DIMM030(D)	•	)		•		•		•		
						נ	DIMM031(J)	0	)	(	О	(	С				
						IMC1	IMC1	IMC1	Е	DIMM040(E)	•	)		•		•	
		4	DIMM041(K)	0	)	(	0										
		E	DIMM050(F)	•	)		•		•	·	)						
									-	DIMM051(L)	0	)					

Configurations in Different Modes (●: DDR4 DIMM O: DCPMM) CPU Channel **DIMM Slot** MM Α DIMM001(G) IMC0 DIMM011(H) C DIMM021(I) CPU1 D DIMM031(J) IMC1 Ε DIMM041(K) F DIMM051(L) DIMM100(A) DIMM101(G) DIMM110(B) DIMM111(H) IMC0 В DIMM111(H)
DIMM120(C)
DIMM121(I)
DIMM130(D)
DIMM131(J)
DIMM140(E)
DIMM141(K)
DIMM150(F)
DIMM151(L) C CPU2 D IMC1 Ε F

Figure 5-30 DCPMM and DDR4 memory configuration guidelines (2 processors)

Figure 5-31 DCPMM and DDR4 memory configuration guidelines

DCPMM and	DCPMM and DDR4 Memory Configuration Guidelines								
Capacity per DCPMM	Single iMC	Matchable Capacity per DDR4 Memory							
capacity per DCF WIW	Installation Method	16 GB	32 GB	64 GB	128 GB				
	2-2-2	$\checkmark$	$\checkmark$	$\checkmark$					
128 GB	2-2-1	$\checkmark$	$\checkmark$						
120 00	2-1-1	$\checkmark$							
	1-1-1	$\checkmark$	$\checkmark$						
	2-2-2	$\checkmark$	$\checkmark$	$\checkmark$	$\sqrt{}$				
256 GB	2-2-1	$\checkmark$	$\checkmark$	$\checkmark$					
250 GB	2-1-1	$\checkmark$	$\checkmark$						
	1-1-1	$\checkmark$	$\checkmark$	$\checkmark$					
	2-2-2		$\checkmark$	$\checkmark$	$\sqrt{}$				
512 GB	2-2-1		$\checkmark$	$\checkmark$	$\sqrt{}$				
312 00	2-1-1	$\checkmark$	$\checkmark$	$\checkmark$					
	1-1-1	$\sqrt{}$		$\sqrt{}$	$\sqrt{}$				

## **5.4.2.6 Memory Protection Technologies**

The following memory protection technologies are supported:

- DCPMM error detection and correction
- DCPMM persistent memory address range scrub (ARS)
- DCPMM data poison
- DCPMM DDR-T fault tolerance

Faulty DCPMM isolation

# 5.5 Storage

# **5.5.1 Drive Configuration**

Table 5-10 Drive configuration

Configuratio n	Maximum Number of Front Drives	Maximum Number of Rear Drives	Maximum Number of Built-in Drives	Normal Drive Management Mode
8 x 2.5" drive pass-through configuration 1	<ul> <li>Front drive: 8 x 2.5"</li> <li>Slots 0 to 7 support only SAS/SATA drives.</li> </ul>	I/O module 3: 4 x 2.5"  Slots 44 to 47 support only NVMe drives.	_	1 x screw-in RAID controller card Screw-in RAID controller card: RAID controller card connector installed on the mainboard.
8 x 2.5" drive pass-through configuration 2	<ul> <li>Front drive: 8 x 2.5"</li> <li>Slots 0 to 7 support only SAS/ SATA drives.</li> </ul>	I/O module 3: 4 x 2.5"  Slots 44 to 47 support only NVMe drives.	-	1 x PCle plug- in RAID controller card PCle plug-in RAID controller card: must be installed in slot 1 or 3.
8 x 2.5" drive pass-through configuration 3	<ul> <li>Front drive: 8 x 2.5"</li> <li>Slots 0 to 7 support only SATA drives.</li> </ul>	-	-	PCH pass- through

Configuratio n	Maximum Number of Front Drives	Maximum Number of Rear Drives	Maximum Number of Built-in Drives	Normal Drive Management Mode
8 x 3.5" drive pass-through configuration 1	<ul> <li>Front drive: 8 x 3.5"</li> <li>Slots 0 to 7 support only SAS/ SATA drives.</li> </ul>	I/O module 3: 4 x 2.5"  Slots 44 to 47 support only NVMe drives.	-	1 x PCIe plug- in RAID controller card <sup>a</sup> The PCIe plug-in RAID controller card must be installed in slot 3.
8 x 3.5" drive pass-through configuration 2	Front drive: 8 x 3.5"  Slots 0 to 7 support only SAS/ SATA drives.	I/O module 3: 4 x 2.5"  Slots 44 to 47 support only NVMe drives.	-	1 x screw-in RAID controller card <sup>b</sup> Screw-in RAID controller card: RAID controller card connector installed on the mainboard

Configuratio n	Maximum Number of Front Drives	Maximum Number of Rear Drives	Maximum Number of Built-in Drives	Normal Drive Management Mode
12 x 3.5" drive EXP configuration 1	Front drive: 12 x 3.5"  Slots 0 to 11 support only SAS/ SATA drives.	I/O module 1: 2 x 2.5"c or 2 x 3.5"  - Slots 40 to 41 support only SAS/ SATA drives.  I/O module 2: 2 x 3.5"  - Slots 42 to 43 support only SAS/ SATA drives.  I/O module 3: 4 x 2.5"  - Slots 44 to 47 support only SAS/ SATA// NVMe drives <sup>d/e</sup> .	Built-in drive: 4x3.5"  - Slots 36 to 39 support only SAS/SATA drivesf.	1 x screw-in RAID controller card Screw-in RAID controller card: RAID controller card connector installed on the mainboard

Configuratio n	Maximum Number of Front Drives	Maximum Number of Rear Drives	Maximum Number of Built-in Drives	Normal Drive Management Mode
12 x 3.5" drive EXP configuration 2	Front drive: 12 x 3.5"  Slots 0 to 11 support only SAS/ SATA drives.	I/O module 1: 2 x 3.5"  Slots 40 to 41 support only SAS/ SATA drives.  I/O module 3: 4 x 2.5"  Slots 44 to 47 support only NVMe drives.		1 x screw-in RAID controller card + 1 x PCIe plug-in RAID controller card 1. Screw-in RAID controller card: RAID controller card connector installed on the mainboard 2. The PCIe plug-in RAID controller card must be installed in slot 6.
12 x 3.5" drive EXP configuration 3	Front drive: 12 x 3.5"  Slots 0 to 11 support only SAS/ SATA drives.	I/O module 1: 2 x 3.5"  Slots 40 to 41 support only SAS/ SATA drives.  I/O module 3: 4 x 2.5"  Slots 44 to 47 support only SAS/ SATA// NVMe drivese.	Built-in drive: 4x3.5"      Slots 36 to 39 support only SAS/SATA drives.	1 x PCIe plug- in RAID controller card <sup>g</sup> The PCIe plug-in RAID controller card must be installed in slot 6.

Configuratio n	Maximum Number of Front Drives	Maximum Number of Rear Drives	Maximum Number of Built-in Drives	Normal Drive Management Mode
12 x 3.5" drive EXP configuration 4	Front drive: 12 x 3.5"  Slots 0 to 11 support only SAS/ SATA drives.	I/O module 1: 2 x 2.5"c  Slots 40 to 41 support only SAS/ SATA drives.  I/O module 2: 2 x 3.5"	-	1 x PCIe plug- in RAID controller card The PCIe plug-in RAID controller card must be installed in slot 3.
		- Slots 42 to 43 support only SAS/ SATA drives.  • I/O module 3: 4 x 2.5" - Slots 44		
		to 47 support only NVMe drives.		

Configuratio n	Maximum Number of Front Drives	Maximum Number of Rear Drives	Maximum Number of Built-in Drives	Normal Drive Management Mode
12 x 3.5" drive pass-through configuration 1	Front drive: 12 x 3.5"  Slots 0 to 11 support only SAS/ SATA drives.	<ul> <li>I/O module         1: 2 x 3.5"         <ul> <li>Slots 40</li> <li>to 41</li> <li>support</li> <li>only</li> <li>SAS/</li> <li>SATA</li> <li>drives.</li> </ul> </li> <li>I/O module         2: 2 x 3.5"         <ul> <li>Slots 42</li> <li>to 43</li> <li>support</li> <li>only</li> <li>SAS/</li> <li>SATA</li> <li>drives.</li> </ul> </li> <li>I/O module         3: 4 x 2.5"         <ul> <li>Slots 44</li> <li>to 47</li> <li>support</li> <li>only</li> <li>NVMe</li> <li>drives.</li> </ul> </li> </ul>		1 x screw-in RAID controller cardh Screw-in RAID controller card: RAID controller card connector installed on the mainboard
12 x 3.5" drive pass-through configuration 2	Front drive: 12 x 3.5"  Slots 0 to 11 support only SATA drives	I/O module 1: 2 x 2.5"c  Slots 40 to 41 support only SATA drives.  I/O module 3: 4 x 2.5"  Slots 44 to 47 support only NVMe drives	-	PCH pass-through

Configuratio n	Maximum Number of Front Drives	Maximum Number of Rear Drives	Maximum Number of Built-in Drives	Normal Drive Management Mode
12 x 3.5" drive pass-through configuration 3	Front drive: 12 x 3.5"  Slots 0 to 11 support only SAS/ SATA drives.	I/O module 3: 4 x 2.5"  Slots 44 to 47 support only SAS/ SATA// NVMe drivese.	Built-in drive: 4x3.5"  - Slots 36 to 39 support only SAS/SATA drives.	1 x screw-in RAID controller cardh + 1 x PCIe plug-in RAID controller card 1. Screw-in RAID controller card: RAID controller card connector installed on the mainboard 2. The PCIe plug-in RAID controller card must be installed in slot 6.

Configuratio n	Maximum Number of Front Drives	Maximum Number of Rear Drives	Maximum Number of Built-in Drives	Normal Drive Management Mode
12 x 3.5" drive pass-through configuration 4	Front drive: 12 x 3.5"  Slots 0 to 11 support only SAS/ SATA drives.	I/O module 1: 2 x 3.5"  Slots 40 to 41 support only SAS/ SATA drives.  I/O module 3: 4 x 2.5"  Slots 44 to 47 support only SAS/ SATA// NVMe drivese/i	_	1 x screw-in RAID controller cardh + 1 x PCIe plug-in RAID controller card 1. Screw-in RAID controller card: RAID controller card connector installed on the mainboard 2. The PCIe plug-in RAID controller card must be installed in slot 6.
20 x 2.5" drive configuration 1 (8 x SAS/ SATA+12 x NVMe)	<ul> <li>Front drive: 20 x 2.5"</li> <li>Slots 0 to 7 support only SAS/SATA drives.</li> <li>Slots 8 to 19 support only NVMe drives.</li> </ul>	I/O module 3: 4 x 2.5"  Slots 44 to 47 support only NVMe drives.	-	1 x screw-in RAID controller card Screw-in RAID controller card: RAID controller card connector installed on the mainboard

Configuratio n	Maximum Number of Front Drives	Maximum Number of Rear Drives	Maximum Number of Built-in Drives	Normal Drive Management Mode
20 x 2.5" drive configuration 2 (8 x SATA +12 x NVMe)	<ul> <li>Front drive: 20 x 2.5"</li> <li>Slots 0 to 7 support only SATA drives.</li> <li>Slots 8 to 19 support only NVMe drives.</li> </ul>	I/O module 3: 4 x 2.5"  Slots 44 to 47 support only NVMe drives.	-	PCH pass-through
24 x 2.5" drive pass-through configuration 1	Front drive: 24 x 2.5"  Slots 0 to 23 support only SAS/ SATA drives.	I/O module 3: 4 x 2.5"  Slots 44 to 47 support only NVMe drives.		1 x screw-in RAID controller card + 2 x PCIe plug-in RAID controller carding 1. Screw-in RAID controller card: RAID controller card connector installed on the mainboard 2. The PCIe plug-in RAID controller card must be installed in slot 3 or 6.

Configuratio n	Maximum Number of Front Drives	Maximum Number of Rear Drives	Maximum Number of Built-in Drives	Normal Drive Management Mode
24 x 2.5" drive pass-through configuration 2	<ul> <li>Front drive: 24 x 2.5"</li> <li>Slots 0 to 23 support only SAS/SATA drives.</li> </ul>	I/O module 3: 4 x 2.5"  Slots 44 to 47 support only NVMe drives.	_	3 x PCIe plug- in RAID controller card <sup>j</sup> The PCIe plug-in RAID controller card must be installed in slot 1, 2 or 6.
24 x 2.5" NVMe drive configuration	<ul> <li>Front drive: 24 x 2.5"</li> <li>Slots 0 to 3 support SAS/SATA/NVMe drives.</li> <li>Slots 4 to 23 support only NVMe drives.</li> </ul>	• I/O module 3: 4 x 2.5"  - Slots 44 to 47 support only NVMe drives.	-	1 x screw-in RAID controller card Screw-in RAID controller card: RAID controller card connector installed on the mainboard
25 x 2.5" drive EXP configuration 1	Front drive: 25 x 2.5"  Slots 0 to 24 support only SAS/ SATA drives.	I/O module 1: 2 x 3.5"  Slots 40 to 41 support only SAS/ SATA drives.  I/O module 3: 4 x 2.5"  Slots 44 to 47 support only NVMe drives.	-	1 x screw-in RAID controller card Screw-in RAID controller card: RAID controller card connector installed on the mainboard

Configuratio n	Maximum Number of Front Drives	Maximum Number of Rear Drives	Maximum Number of Built-in Drives	Normal Drive Management Mode
25 x 2.5" drive EXP configuration 2	• Front drive: 25 x 2.5"  - Slots 0 to 24 support only SAS/SATA drives.	I/O module 1: 2 x 3.5"  Slots 40 to 41 support only SAS/ SATA drives.  I/O module 3: 4 x 2.5"  Slots 44 to 47 support only NVMe drives.	-	1 x screw-in RAID controller card + 1 x PCIe plug-in RAID controller card 1. Screw-in RAID controller card: RAID controller card connector installed on the mainboard 2. The PCIe RAID controller card must be installed in slot 6.

Configuratio n	Maximum Number of Front Drives	Maximum Number of Rear Drives	Maximum Number of Built-in Drives	Normal Drive Management Mode
25 x 2.5" drive EXP configuration 3	• Front drive: 25 x 2.5"  - Slots 0 to 24 support only SAS/SATA drives.	I/O module 1: 2 x 2.5"  Slots 40 to 41 support only SAS/ SATA drives.  I/O module 3: 4 x 2.5"  Slots 44 to 47 support only SAS/ SATA// NVMe drivese/k .		1 x PCle plugin RAID controller card PCle plugin RAID controller card  PCle plugin RAID controller card configured in I/O module 1 must be installed in slot 3.  PCle plugin RAID controller card configured in I/O module 2 must be installed in slot 6.

n Number of Nu	Maximum Imber of Par Drives  Maximum Number of Built-in Drives	Normal Drive Management Mode
----------------	----------------------------------------------------------------	------------------------------------

- a: For now, this configuration only supports Avago MegaRAID SAS 9440-8i (P/N: 02312QWY) and Avago MegaRAID SAS 9460-8i (P/N: 02312QWV) PCIe plug-in RAID controller card.
- b: For now, this configuration only supports LSI SAS3108 screw-in RAID controller card.
- c: The rear I/O module 1 (2 x 2.5") uses the module "Rear HDD + PCle Riser Module", for details, see 5.7.2 PCle Slots.
- d: Only when Avago SAS3416iMR, Avago SAS3416IT screw-in RAID controller cards are configured, I/O module 3 supports SAS/SATA drives.
- e: All slots support mixed installation of SAS/SATA/NVMe drives.
- f: Only when Avago SAS3416iMR, Avago SAS3416IT screw-in RAID controller cards are configured, built-in drive is supported.
- g: Normal drive management mode only supports Avago SAS3516 PCle plug-in RAID controller card.
- h: Normal drive management mode only supports Avago SAS3416iMR, Avago SAS3416IT screw-in RAID controller card.
- i: Only when Avago SAS3416iMR, Avago SAS3416IT screw-in RAID controller cards are configured, I/O module 3 supports NVMe drives.
- j: Normal drive management rmode equires one RAID controller card for every eight front drives. A maximum of three RAID controller cards are supported.
- k: Only when Avago SAS3516 PCle plug-in RAID controller card is configured, I/O module 3 supports SAS/SATA drives.
- Contact your local sales representative or use the Compatibility Checker to determine the components to be used.


## 5.5.2 Drive Numbering

#### □ NOTE

When the common hard drive management mode is PCH, each SATA drive has a fixed ATA number. ATA numbers provided in this section are based on the assumption that the hard drive management mode is PCH. The following table lists the mapping between ATA numbers and physical hard drive numbers.

 8 x 2.5" drive pass-through configuration 1 and 8 x 2.5" drive pass-through configuration 2

Figure 5-32 Drive numbering






• 8 x 2.5" drive pass-through configuration 3

Figure 5-33 Drive numbering



 8 x 3.5" drive pass-through configuration 1 and 8 x 3.5" drive pass-through configuration 2

Figure 5-34 Drive numbering



• 12 x 3.5" drive EXP configuration 1

.....

36 37 38 38

Figure 5-35 Drive numbering (I/O module 1 with 2 x 3.5" SAS/SATA drives)

12 x 3.5" drive EXP configuration 2

Figure 5-36 Drive numbering




12 x 3.5" drive EXP configuration 3

Figure 5-37 Drive numbering



• 12 x 3.5" drive EXP configuration 4

Figure 5-38 Drive numbering



• 12 x 3.5" drive pass-through configuration 1

Figure 5-39 Drive numbering



• 12 x 3.5" drive pass-through configuration 2

Figure 5-40 Drive numbering




Table 5-11 SATA drive numbers

Drive No.	ATA No.
0	ATA3
1	ATA4
2	ATA5
3	ATA6
4	ATA7
5	ATA8
6	ATA9
7	ATA10
8	ATA11
9	ATA12
10	ATA13

Drive No.	ATA No.
11	ATA14


• 12 x 3.5" drive pass-through configuration 3

Figure 5-41 Drive numbering



12 x 3.5" drive pass-through configuration 4

Figure 5-42 Drive numbering



• 20 x 2.5" (8 x SAS/SATA + 12 x NVMe) drive configuration

Figure 5-43 Drive numbering




Table 5-12 SATA drive numbers

Drive No.	ATA No.
0	ATA3
1	ATA4
2	ATA5
3	ATA6
4	ATA7
5	ATA8
6	ATA9
7	ATA10

• 24 x 2.5" drive configuration

Figure 5-44 Drive numbering




Table 5-13 SATA drive numbers

Drive No.	ATA No.	
0	ATA3	

Drive No.	ATA No.
1	ATA4
2	ATA5
3	ATA6

• 25 x 2.5" drive EXP configuration 1

Figure 5-45 Drive numbering





• 25 x 2.5" drive EXP configuration 2


Figure 5-46 Drive numbering





• 25 x 2.5" drive EXP configuration 3

Figure 5-47 Drive numbering



## 5.5.3 Drive Indicators

### **SAS/SATA Drive Indicators**

Figure 5-48 SAS/SATA drive indicators





Table 5-14 Description of SAS/SATA drive indicators

Activity Indicator (Green)	Fault Indicator (Yellow)	Description
Off	Off	The drive is not in position.
Steady on	Off	The drive is detected.
Blinking at 4 Hz	Off	Data is being read or written normally, or data on the primary drive is being rebuilt.
Steady on	Blinking at 1 Hz	The drive is being located.
Blinking at 1 Hz	Blinking at 1 Hz	Data on the secondary drive is being rebuilt.
Off	Steady on	A member drive in the RAID array is removed.
Steady on	Steady on	The drive is faulty.

### **NVMe Drive Indicators**

Figure 5-49 NVMe drive indicators



• If the VMD function is enabled and the latest VMD driver is installed, the NVMe drives support surprise hot swap.

Table 5-15 NVMe drive indicators (VMD enabled)

Activity Indicator (Green)	Fault Indicator (Yellow)	Description
Off	Off	The NVMe drive cannot be detected.
Steady on	Off	The NVMe drive is working properly.
Blinking at 2 Hz	Off	Data is being read from or written to the NVMe SSD.
Steady on	Blinking at 2 Hz	The NVMe drive is being located.
Steady on/Off	Steady on	The NVMe drive is faulty.

• If the VMD function is disabled, NVMe drives support only orderly hot swap.

Table 5-16 NVMe drive indicators (VMD disabled)

Activity Indicator (Green)	Fault Indicator (Yellow)	Description	
Off	Off	The NVMe drive cannot be detected.	
Steady on	Off	The NVMe drive is working properly.	
Blinking at 2 Hz	Off	Data is being read from or written to the NVMe drive.	
Off	Blinking at 2 Hz	The NVMe drive is being located or hot-swapped.	
Off	Blinking at 0.5 Hz	The hot removal process is complete, and the NVMe drive is removable.	

Activity Indicator (Green)	Fault Indicator (Yellow)	Description
Steady on/Off	Steady on	The NVMe drive is faulty.

### **M.2 FRU Indicators**

Figure 5-50 M.2 FRU indicators




Table 5-17 M.2 FRU indicator description

Indicator	Description
M.2 FRU fault indicator	<ul> <li>Off: The M.2 FRU is running properly.</li> <li>Blinking yellow: The M.2 FRU is being located, or RAID is being rebuilt.</li> <li>Steady yellow: The M.2 FRU is faulty or not detected.</li> </ul>
M.2 FRU activity indicator	<ul> <li>Off: The M.2 FRU is not in position or is faulty.</li> <li>Blinking green: Data is being read, written, or synchronized.</li> <li>Steady green: The M.2 FRU is inactive.</li> </ul>

## 5.5.4 RAID Controller Card

The RAID controller card supports RAID configuration, RAID level migration, and drive roaming.

- Contact your local sales representative or use the Compatibility Checker to determine the components to be used.
- For details about the RAID controller card, see V5 Server RAID Controller Card User Guide.

## 5.6 Network

### 5.6.1 LOMs


LOMs provide network expansion capabilities.

**Table 5-18** LOM description

NIC Type	Chip Model	Port Type	Numb er of Ports	Rate Negotiatio n Mode	Supported Rates	Rates Not Supported
LOMs	X722	10GE optical port	2	Auto- negotiation 10,000 Mbit/s (full duplex)	10000M	10/100/100 OM
		10GE electrica I port	2	Auto- negotiation 1000 Mbit/s (full duplex)	1000M	10/100M
				Auto- negotiation 10,000 Mbit/s (full duplex)	10000M	10/100M
		GE electrica I port	2	Auto- negotiation 1000 Mbit/s (full duplex)	1000M	10/100M

- Use **Compatibility Checker** to obtain information about the cables and optical modules supported by the LOM ports.
- The LOM ports support NC-SI, WOL, and PXE.
- The LOM ports do not support forced rates.
- The electrical LOM ports cannot be connected to power over Ethernet (PoE) devices (such as a switch with PoE enabled). Connecting a LOM port to a PoE device may cause link communication failure or even damage the NIC.
- The electrical LOM ports (GE electrical ports) do not support SR-IOV.
- Forcibly powering off a server will cause intermittent NC-SI disconnection and disable the WOL function of the LOM ports. To restore the NC-SI connection, refresh the iBMC WebUI.


Figure 5-51 LOM port



1	(Optional) 10GE optical port (LOM port 1)	2	(Optional) 10GE optical port (LOM port 2)
3	(Optional) 10GE electrical port (LOM port 1)	4	(Optional) 10GE electrical port (LOM port 2)
5	GE electrical port (LOM GE port 1)	6	GE electrical port (LOM GE port 2)

## **Indicator Positions**

Figure 5-52 LOM indicators



indic stat	nection status cator/Data transmission us indicator for a 10GE cal port	2	Data transmission rate indicator for a 10GE optical port
---------------	----------------------------------------------------------------------------------	---	----------------------------------------------------------

3	Data transmission rate indicator for a 10GE electrical port	4	Connection status indicator/Data transmission status indicator for a 10GE electric port
5	Data transmission status indicator of a GE electrical port	6	Connection status indicator of a GE electrical port

## **Indicator Description**

Table 5-19 LOM indicators

Indicator	Description	
Connection status indicator/Data transmission status indicator for a 10GE optical port	<ul> <li>Off: The network port is not connected.</li> <li>Blinking green: Data is being transmitted.</li> <li>Steady green: The network port is properly connected.</li> </ul>	
Data transmission rate indicator for a 10GE optical port	<ul> <li>Off: The network port is not connected.</li> <li>Steady green: The data transmission rate is 10 Gbit/s.</li> </ul>	
Connection status indicator/Data transmission status indicator for a 10GE electric port	<ul> <li>Off: The network port is not connected.</li> <li>Blinking green: Data is being transmitted.</li> <li>Steady green: The network port is properly connected.</li> </ul>	
Data transmission rate indicator for a 10GE electrical port	<ul> <li>Off: The network port is not connected.</li> <li>Steady green: The data transmission rate of the link is 10 Gbit/s.</li> <li>Steady yellow: The data transmission rate of the link is 1 Gbit/s.</li> </ul>	
Connection status indicator of a GE electrical port	<ul> <li>Off: The network port is not connected.</li> <li>Steady green: The network port is properly connected.</li> </ul>	
Data transmission status indicator of a GE electrical port	<ul> <li>Off: Inactive.</li> <li>Steady yellow: Active, but no data is being transmitted.</li> <li>Blinking yellow: Data is being transmitted.</li> </ul>	

# 5.6.2 FlexIO Cards

FlexIO cards provide network expansion capabilities.

- The FlexIO card (with electrical ports) cannot be connected to power over Ethernet (PoE) devices (such as a switch with PoE enabled). Otherwise, link communication failure or even damage to the FlexIO card may be caused.
- Contact your local sales representative or use the Compatibility Checker to determine the components to be used.
- When IB cards are used to build an IB network, ensure that the IPoIB modes of the IB cards at both ends of the network are the same. For details, contact technical support.


**Table 5-20** FlexIO cards supported by the 2288H V5 (example)

NIC Model	Chip Model	Port Type	Number of Ports	Support NC- SI/WOL/PXE
SM210	5719	GE electrical port	4	V
SM211	i350	GE electrical port	2	V
SM212	i350	GE electrical port	4	V
SM233	X540	10GE electrical port	2	V
SM251	CX3	56G IB optical port	2	×
SM252	СХЗ	56G IB optical port	1	×
SM330	X710	10GE optical port	2	V
SM380	CX4	25GE optical port	2	V

### **Indicator Positions**


SM210/SM212 with four GE electrical ports

Figure 5-53 SM210/SM212 network port indicators



• SM211 with two GE electrical ports

Figure 5-54 SM211 network port indicators



• SM233 with two 10GE electrical ports

Figure 5-55 SM233 network port indicators



SM251 with two 56G IB optical ports

Figure 5-56 SM251 network port indicators



Connection status indicator Data transmission status indicator

• SM252 with one 56G IB optical port

Figure 5-57 SM252 network port indicators



Connection status indicator Data

Data transmission status indicator

• SM330 with two 10GE optical ports/SM380 with two 25GE optical ports

Figure 5-58 SM330/SM380 network port indicators



Connection status indicator/data transmission status indicator

## **Indicator Description**

Table 5-21 FlexIO card indicator description

Port Type	Indicator	Description
GE electrical port	Data transmission status indicator	<ul><li>Off: No data is being transmitted.</li><li>Blinking yellow: Data is being transmitted.</li></ul>

Port Type	Indicator	Description
	Connection status indicators	<ul> <li>Off: The network port is not connected.</li> <li>Steady green: The network port is properly connected.</li> </ul>
10GE electrical port	Transmission rate indicator	<ul> <li>Off: The data transmission rate is 10/100 Mbit/s.</li> <li>Steady green: The data transmission rate is 10 Gbit/s.</li> <li>Steady yellow: The data transmission rate is 1 Gbit/s.</li> </ul>
	Connection status indicator/Data transmission status indicator	<ul> <li>Off: No data is being transmitted or the network port is not connected.</li> <li>Blinking green: Data is being transmitted.</li> <li>Steady green: The network port is properly connected.</li> </ul>
10GE optical port	Transmission rate indicator	<ul> <li>Off: The network port is not connected or the data transmission rate is 100 Mbit/s.</li> <li>Steady green: The data transmission rate is 10 Gbit/s.</li> <li>Steady yellow: The data transmission rate is 1 Gbit/s.</li> </ul>
	Connection status indicator/Data transmission status indicator	<ul> <li>Off: The network port is not connected.</li> <li>Blinking green: Data is being transmitted.</li> <li>Steady green: The network port is connected properly.</li> </ul>
25GE optical port	Transmission rate indicator	<ul> <li>Off: The network port is not connected.</li> <li>Steady green: The data transmission rate is 25 Gbit/s.</li> <li>Steady yellow: The data transmission rate is 10 Gbit/s.</li> </ul>
	Connection status indicator/Data transmission status indicator	<ul> <li>Off: The network port is not connected.</li> <li>Blinking green: Data is being transmitted.</li> <li>Steady green: The network port is properly connected.</li> </ul>

Port Type	Indicator	Description
56G IB optical port Connection status indicators	<ul> <li>Off: No physical link is set up.</li> <li>Blinking green: The physical link is abnormal.</li> <li>Steady green: The physical link is</li> </ul>	
	Data transmission status indicator	<ul> <li>Off: No logical link is set up.</li> <li>Blinking yellow: Data is being transmitted.</li> <li>Steady yellow: The logical link is normal but no data is being transmitted.</li> </ul>

## 5.7 I/O Expansion

## 5.7.1 PCIe Cards

PCIe cards provide ease of expandability and connection.

- The electrical ports provided by PCIe NICs cannot be connected to power over Ethernet (PoE) devices (such as a switch with PoE enabled). Connecting such an electrical port to a PoE device may cause link communication failure or even damage the NIC.
- Contact your local sales representative or use the Compatibility Checker to determine the components to be used.
- When IB cards are used to build an IB network, ensure that the IPoIB modes of the IB cards at both ends of the network are the same. For details, contact technical support.

## 5.7.2 PCIe Slots

#### **PCIe Slots**

Figure 5-59 PCIe slots



- I/O module 1 provides slots 1 to 3. If a dual-slot PCle riser module is used, slot 2 is unavailable.
- I/O module 2 provides slots 4 to 6. If a dual-slot PCle riser module is used, slot 5 is unavailable.

I/O module 3 provides slots 7 to 8. If a single-slot PCle riser module is used, slot 8 is unavailable.

#### **◯** NOTE

- Observe the following when configuring PCle GPU cards:
  - A dual-slot PCIe riser module in I/O module 1 or 2 can house only one FHFL singleslot or dual-slot PCIe x16 GPU card in slot 1 or 4.
  - A three-slot PCle riser module in I/O module 1 or 2 does not support dual-slot GPU card.
  - A single-slot PCle riser module in I/O module 3 can house only one HHHL single-slot x16 GPU card.
  - I/O module 3 does not support GPU cards when it is installed with a dual-slot PCIe riser module.
  - The Tesla T4 or Tesla P4 HHHL GPU supports x16 and x8 configurations. If x16 is used, a maximum of four GPUs can be installed in slots 1, 3, 4, and 7. If x8 is used, a maximum of seven GPUs can be installed in slots 1 to 7.
  - Dedicated PCIe riser module must be used with Tesla T4 and dual-slot GPU cards.
- Observe the following rules when configuring NVMe SSD adapters:
  - If 24 x 2.5" NVMe drives are configured, two NVMe SSD adapters must be installed in slots 1 and 4.


#### **PCle Riser Modules**

PCle riser module 1 (universal)

Figure 5-60 PCIe riser module 1

- It provides PCIe slots 1 and 3 when being installed in I/O module 1.
- It provides PCIe slots 4 and 6 when being installed in I/O module 2.






PCle riser module 2 (universal)


- It provides PCIe slots 1, 2, and 3 when being installed in I/O module 1.
- It provides PCle slots 4, 5, and 6 when being installed in I/O module 2.

Figure 5-61 PCle riser module 2




- PCle riser module 3 (for GPUs only)
  - It provides PCle slots 1 and 3 when being installed in I/O module 1.
  - It provides PCIe slots 4 and 6 when being installed in I/O module 2.

Figure 5-62 PCle riser module 3




PCle riser module 4 (for T4 GPUs only)
 Provides PCle slots 1 and 3 when installed in I/O module 1.

Figure 5-63 PCle riser module 4



PCIe riser module 5
 Provides PCIe slots 7 and 8 when installed in I/O module 3.

Figure 5-64 PCle riser module 5



PCIe riser module 6
 It provides PCIe slot 7 when being installed in I/O module 3.

PSU connector
Slimline A connector
Slimline B connector

Figure 5-65 PCle riser module 6

PCIe riser module 7 (rear drives and a PCIe Riser card)
 Provides PCIe slot 3 when installed in I/O module 1.




Figure 5-66 PCIe riser module 7

## **5.7.3 PCIe Slot Description**

**◯** NOTE

The PCIe slots mapping to a vacant CPU socket are unavailable.

Table 5-22 PCle slot description

PCIe Slot	CPU	PCIe Stand ards	Conne ctor Width	Bus Width	Port No.	Root Port (B/D/F )	Devic e (B/D/F )	Slot Size
RAID control ler card	CPU 1	PCIe 3.0	x8	x8	Port1C	17/02/ 0	1D/ 00/0	-
LOM	CPU 1	PCle 3.0	x8	x8	Port1A	17/00/ 0	1A/ 00/0	-
FlexIO card	CPU 2	PCle 3.0	x8	x8	Port2A	AE/ 00/0	AF/ 00/0	-
Slot 1	CPU 1	PCIe 3.0	x16	• 2- slot PCI e rise r mo dul e (PR M): x16 • 3- slot PR M: x8	Port2A	3A/ 00/0	3B/ 00/0	FHFL
Slot 2	CPU 1	PCIe 3.0	x16	• 2- slot PR M: N/A • 3- slot PR M: x8	Port2C	3A/ 02/0	3E/ 00/0	FHFL
Slot 3	CPU 1	PCle 3.0	x16	х8	Port3A	5D/ 00/0	5E/ 00/0	FHHL

PCIe Slot	CPU	PCIe Stand ards	Conne ctor Width	Bus Width	Port No.	Root Port (B/D/F )	Devic e (B/D/F )	Slot Size
Slot 4	CPU 2	PCIe 3.0	x16	• 2- slot PR M: x16 • 3- slot PR M: x8	Port1A	85/00/ 0	86/00/	FHFL
Slot 5	CPU 2	PCIe 3.0	x16	• 2- slot PR M: N/A • 3- slot PR M: x8	Port1C	85/02/ 0	89/00/ 0	FHFL
Slot 6	CPU 2	PCle 3.0	x16	х8	Port2C	AE/ 02/0	B0/00/ 0	FHHL
Slot 7	CPU 2	PCIe 3.0	x16	• Sin gle-slot PR M: x16 • 2-slot PR M: x8	Port3A	D7/00/ 0	D8/00/ 0	HHHL

PCIe Slot	CPU	PCIe Stand ards	Conne ctor Width	Bus Width	Port No.	Root Port (B/D/F )	Devic e (B/D/F )	Slot Size
Slot 8	CPU 2	PCIe 3.0	x8	• Sin gle-slot PR M: N/A	Port3C	D7/02/ 0	DB/ 00/0	HHHL
				• 2- slot PR M: x8				

- The B/D/F (Bus/Device/Function Number) values are the default values when the server is fully configured with PCIe devices. The values may vary if the server is not fully configured with PCIe devices or if a PCIe card with a PCI bridge is configured.
- Root Port (B/D/F) indicates the B/D/F of an internal PCle root port of the processor.
- Device (B/D/F) indicates the B/D/F (displayed on the OS) of an onboard or extended PCIe device.
- The PCle x16 slots are backward compatible with PCle x8, PCle x4, and PCle x1 cards. The PCle cards are not forward compatible. That is, the PCle slot width cannot be smaller than the PCle card link width.
- Full-height full-length PCIe slots are backward compatible with full-height half-length and half-height half-length PCIe cards. Full-height half-length PCIe slots are backward compatible with half-height half-length PCIe cards.
- All slots support PCIe cards of up to 75 W. The power of a PCIe card varies depending on its model.
- The SP520, SP521, and SP522 do not support driveless server configuration. PXE boot is recommended for driveless servers.

## 5.8 PSUs

- The server supports one or two PSUs.
- The server supports AC or DC PSUs.
- The PSUs are hot-swappable.
- The server supports two PSUs in 1+1 redundancy.
- The same model of PSUs must be used in a server.
- The PSUs are protected against short circuit. Double-pole fuse is provided for the PSUs with dual input live wires.

- If the DC power supply is used, purchase the DC power supply that meets the requirements of the safety standards or the DC power supply that has passed the CCC certification.
- Contact your local sales representative or use the Compatibility Checker to determine the components to be used.

#### **◯** NOTE

- When one or two 900 W AC Titanium PSUs are configured and the input voltage ranges from 100 V AC to 127 V AC, the output power decreases to 550 W.
- When one or two 1500 W AC Platinum PSUs are configured, When the input voltage ranges from 100 V AC to 127 V AC, the output power decreases to 1000 W.

#### Figure 5-67 PSU positions



## **5.9 Fans**

- The server supports four fan modules.
- The fan modules are hot-swappable.
- The server tolerates failure of a single fan.
- The fan speed can be adjusted.
- The same model of fan modules must be used in a server.





Figure 5-68 Fan module positions

## 5.10 Boards

## 5.10.1 Mainboard

## **NOTE**

- BOM code for mainboards of enhanced management chip (VB): 0302021706, 0302Y076.
- BOM code for mainboards of normal management chip: 03024AFQ, 03026NEA, 06410432, 03024CXS, 03029JRP, 06410436, 06410592.



**Figure 5-69** 2288H V5 mainboard (BOM: 03024AFQ, 03026NEA, 03024CXS, 03029JRP, 0302021706, 0302Y076, 06410432, 06410436, 06410592)

1	USB 3.0 port (USB 3.0 CONN/J169)	2	UID indicator (D6020)
3	Serial port	4	Management network port
5	GE electrical port	6	GE electrical port
7	VGA connector (VGA CONN/J112)	8	10GE optical port (10GE PORT2/J132) or 10GE electrical port (10GE PORT2/J101) <sup>a</sup>
9	10GE optical port (10GE PORT1/J131) or 10GE electrical port (10GE PORT1/J100) <sup>a</sup>	10	VROC key port (J130) <sup>b</sup>

11	PCIe riser 1 slot (corresponding to CPU 1/ J108)	12	Rear drive backplane power connector 2 (REAR BP PWR2/J126)
13	NC-SI connector (NCSI CONN/J99)	14	SATA signal connector 2 (SATA2/J71)
15	SATA signal connector 1 (SATA1/J67)	16	CPU 1 slimline connector (CPU1 SLIMELINE/J170)
17	Mini SAS HD connector C (MINIHD PORT C/J85)	18	Mini-SAS HD connector B (MINIHD PORT B/J84)
19	Mini SAS HD connector A (MINIHD PORT A/J86)	20	Rear drive backplane power connector 1 (REAR BP PWR1/J127)
21	USB 3.0 port (FRONT USB3.0/J173) <sup>c</sup>	22	Right mounting ears connector (RCIC/RCIF/ RCIG BOARD/J167)
23	TPM/TCM port (TPM CONN/J55)	24	LCD connector (LCD CONN/J87)
25	VGA connector (VGA BOARD/J160)	26	Fan 4 connector (2U FAN4/ J148)
27	Fan 3 connector (2U FAN3/ J145)	28	Fan 2 connector (2U FAN2/ J146)
29	Fan 1 connector (1U/2U FAN1/J105)	30	Drive backplane connector (HDD BP CONN/J162)
31	RTC battery (CMOS BATTERY/U4042)	32	Inner drive power connector (INNER HDD PWR/J171)
33	Drive backplane power connector 1 (HDD BP PWR2/J128)	34	Drive backplane power connector 2 (HDD BP PWR2/J166)
35	Rear drive backplane power connector 3 (REAR BP PWR3/J172)	36	Rear 4 x 2.5" drive backplane low-speed signal connector (REAR 4*2.5 HDD BP/J164)
37	CPU2 slimline A connector (CPU2 SLIMLINE A/J140)	38	CPU2 slimline B connector (CPU2 SLIMLINE B/J139)
39	PSU 2 connector (J157)	40	PSU 1 connector (J156)
41	Inner drive low-speed signal connector (INNER HDD BP/J122)	42	Left mounting ear connector (LCIA BOARD/ J161)
43	Jumper (J176) <sup>d</sup>	44	I/O NIC connectors (IO BOARD/J159/J158)

45	Screw-in RAID controller	46	PCle riser 2 slot
	card connector (RAID		(corresponding to CPU 2/
	CARD/J48)		J155/J116)


- a: "10GE optical port" corresponds to the mainboard (BOM: 03024AFQ and 03026NEA) integrated with two 10GE optical ports and two GE electrical ports.
   "10GE electrical port" corresponds to the mainboard (BOM: 03024CXS and 03029JRP) integrated with two 10GE and two GE electrical ports.
- b: The port is reserved.
- c:The built-in USB 3.0 port can be connected to the front USB 3.0 port through a USB cable. It cannot be used directly.
- d:COM\_SW(ON) is used to change the connection direction of the physical serial port. BMC\_RCV(ON) is used to restore the default iBMC configuration (for iBMC V350 and later versions, restoring the default iBMC configuration through a jumper is not supported).

## 5.10.2 Drive Backplane

## **Front-Drive Backplanes**

• 8 x 2.5" drive pass-through backplane


**Figure 5-70** 8 x 2.5" drive pass-through backplane (BOM: 03022HXW and 03029JRY)



1	Front VGA connector (J26)	2	Backplane signal cable connector (J1)
3	DVD drive power connector (J11)	4	Mini-SAS HD connector (PORT B/J29)
5	Mini-SAS HD connector (PORT A/J28)	6	Power connector (J24)

• 12 x 3.5" drive EXP backplane


**Figure 5-71** 12 x 3.5" drive EXP backplane (BOM: 03024DDH, 03024MSG, 03029JSA, and 0302Y070)



1	Indicator signal cable connector (J32)	2	Mini-SAS HD connector (PORT A/J28)
3	Mini-SAS HD connector (PORT B/J29)	4	Mini-SAS HD connector (REAR PORT/J31)
5	Backplane signal cable connector (J1)	6	Power connector (J24)
7	Indicator signal cable connector (J35)	-	-

• Backplane for the 8 x 3.5" drive pass-through configuration and 12 x 3.5" drive pass-through configuration

**Figure 5-72** Backplane for the 8 x 3.5" drive pass-through configuration and 12 x 3.5" drive pass-through configuration (BOM: 03024JMV and 03029TDH)




1	Indicator signal cable connector (J30)	2	Mini-SAS HD connector (PORT C/J36)
3	Mini-SAS HD connector (PORT B/J29)	4	Backplane signal cable connector (J1)
5	Mini-SAS HD connector (PORT A/J28)	6	Indicator signal cable connector (J31)
7	Power connector (J24)	-	-

• 20 x 2.5" (8 x SAS/SATA + 12 x NVMe) drive pass-through backplane

**◯** NOTE


The 20 x 2.5" (8 x SAS/SATA + 12 x NVMe) drive configuration supports two types of backplanes (BOM codes: 03029TDE and 03025EUL).

**Figure 5-73** 20 x 2.5" (8 x SAS/SATA + 12 x NVMe) drive pass-through backplane (BOM: 03029TDE)



1	Slimline connector (PORT 2C/J31)	2	Slimline connector (PORT 1C/J19)
3	Slimline connector (PORT 1B/J18)	4	Slimline connector (PORT 1A/J17)
5	Mini-SAS HD connector (PORT B/J16)	6	Mini-SAS HD connector (PORT A/J15)
7	Backplane signal cable connector (J41)	8	Power connector (J37)
9	Slimline connector (PORT 2A/J21)	10	Slimline connector (PORT 2B/J32)

**Figure 5-74** 20 x 2.5" (8 x SAS/SATA + 12 x NVMe) drive pass-through backplane (BOM: 03025EUL)




1	Slimline connector (SLIM_B/ J29)	2	Slimline connector (SLIM_A/ J30)
3	Slimline connector (PORT 2C/J31)	4	Slimline connector (PORT 1C/ J19)
5	Slimline connector (PORT 1B/J18)	6	Slimline connector (PORT 1A/ J17)

7	Mini SAS HD connector (PORT B/J16)	8	Mini SAS HD connector (PORT A/J15)
9	Backplane signal cable connector (J41)	10	Power connector (J13)
11	Power connector (J37)	12	Slimline connector (PORT 2A/ J21)
13	Slimline connector (PORT 2B/J32)	-	-

## • 24 x 2.5" drive pass-through backplane


**Figure 5-75** 24 x 2.5" drive pass-through backplane (BOM: 03022JWW, 03029WFE)



1	Mini-SAS HD connector (PORT 3B/J33)	2	Mini-SAS HD connector (PORT 3A/J39)
3	Mini-SAS HD connector (PORT 2B/J31)	4	Mini-SAS HD connector (PORT 2A/J30)
5	Mini-SAS HD connector (PORT 1B/J29)	6	Backplane signal cable connector (J1)
7	Mini-SAS HD connector (PORT 1A/J28)	8	Power connector (J24)

## • 24 x 2.5" NVMe backplane

**Figure 5-76** 24 x 2.5" NVMe backplane (BOM: 03023WAD)




1 Slimline A connector (J6)	2	Slimline B connector (J5)
-----------------------------	---	---------------------------

3	Slimline C connector (J7)	4	Slimline D connector (J8)
5	Power connector 2 (J34)	6	Mini-SAS HD connector (PORT A/J52)
7	Backplane signal cable connector (J3)	8	Power connector 1 (J2)

## • 25 x 2.5" drive EXP backplane

**Figure 5-77** 25 x 2.5" drive EXP backplane (BOM: 03022HYB, 03024MSH, 03029TDQ, and 0302Y071)



1	Indicator signal cable connector (J32)	2	Mini-SAS HD connector (PORT A/J28)
3	Mini-SAS HD connector (PORT B/J29)	4	Mini-SAS HD connector (REAR PORT/J31)
5	Backplane signal cable connector (J1)	6	Power connector (J24)
7	Indicator signal cable connector (J35)	-	-

## **Built-in-Drive Backplane**

• 4 x 3.5" built-in-drive pass-through backplane

Figure 5-78 4 x 3.5" built-in-drive pass-through backplane (BOM: 03024MBJ)




1	Mini-SAS HD connector (PORT A/J3)	2	Backplane signal cable connector (INNER HDD BP/J1)
3	Power connector (INNER HDD PWR/J2)	-	-

## **Rear-Drive Backplanes**

• 2 x 2.5" drive pass-through backplane


**Figure 5-79** 2 x 2.5" drive pass-through backplane (BOM 03022HYD)



1	Mini-SAS HD connector (REAR PORT/J3)	2	Indicator signal cable connector (REAR BP/ J24)
3	Power connector (BP PWR/J1)	-	-

• 2 x 3.5" drive pass-through backplane


**Figure 5-80** 2 x 3.5" drive pass-through backplane (BOM: 03022HYE)



1	Mini-SAS HD connector (REAR PORT/J3)	2	Indicator signal cable connector (REAR BP/ J24)
3	Power connector (BP PWR/J1)	-	-

## • 4 x 2.5" drive pass-through backplane

**Figure 5-81** 4 x 2.5" drive pass-through backplane (BOM: 03024BPV and 03029TDR)



1	Power connector (REAR BP POWR3/J22)	2	Mini-SAS HD connector (Port A/J2)
3	Slimline A connector (SLIMLINE A/J8)	4	Slimline B connector (SLIMLINE B/J9)
5	Backplane signal cable connector (HDD BP/J23)	-	-

# 6 Product Specifications

- 6.1 Technical Specifications
- 6.2 Environmental Specifications
- 6.3 Physical Specifications

## **6.1 Technical Specifications**

Table 6-1 Technical Specifications

Component	Specifications	
Form factor	2U rack server	
Chipset	Intel® C622	
Processor	Supports one or two processors.  Intel® Xeon® Scalable (Skylake and Cascade Lake) processors  Built-in memory controller and six memory channels  Built-in PCle controller, supporting PCle 3.0 and 48 lanes per processor  Two UPI buses between processors, providing up to 10.4GT/s transmission per channel  Up to 28 cores per processor  Max. 3.8 GHz  Min. 1.375 MB L3 cache per core  Max. 205 W TDP  NOTE	
	The preceding information is for reference only. Use the Compatibility Checker to obtain specific information.	

Component	Specifications
DIMM	Supports 24 memory modules of the following types:  • Up to 24 DDR4 memory modules  - Max. 2933 MT/s memory speed  - RDIMM and LRDIMM support  - The DDR4 memory modules of different types
	(RDIMM and LRDIMM) and specifications (capacity, bit width, rank, and height) cannot be used together.
	Up to 12 DCPMMs
	<ul> <li>The DCPMMs must be used with DDR4 memory modules together.</li> </ul>
	<ul> <li>The DCPMMs support the AD or MM mode.</li> </ul>
	<ul> <li>Max. 2666 MT/s memory speed</li> </ul>
	<ul> <li>The DCPMMs of different specifications cannot be used together.</li> </ul>
	<ul> <li>For details about the DCPMMs, see the         FusionServer PMem 200-Barlow Pass User         Guide.     </li> </ul>
	NOTE The preceding information is for reference only. Use the Compatibility Checker to obtain specific information.

Component	Specifications
Storage	Supports a variety of drive configurations. For details, see <b>5.5.1 Drive Configuration</b> .
	Supports two M.2 SSDs.
	<ul> <li>M.2 SSDs are supported for RAID 0/1 and hot swap without opening the chassis cover is supported when the server is configured with an Avago SAS3004iMR RAID controller card.</li> </ul>
	- The drive letter of the M.2 SSDs managed by the Avago SAS3004iMR RAID controller card can be set to <b>sda</b> by modifying the GRUB parameters only when the RAID controller card is used with an SR130, SR760IT-M, SP150IT-M, or SmartRAID 3152-8i RAID controller card or a PCH.
	NOTE
	The M.2 SSD module is used only as the boot device when the OS is installed. Small-capacity (32 GB or 64 GB) M.2 SSDs do not support logging due to poor endurance. If a small-capacity M.2 SSD is used as the boot device, a dedicated log drive or log server is required for logging. For example, you can dump VMware logs in either of the following ways:
	<ul> <li>Redirect /scratch. For details, see https:// kb.vmware.com/s/article/1033696.</li> </ul>
	<ul> <li>Configure syslog. For details, see <a href="https://kb.vmware.com/s/article/2003322">https://kb.vmware.com/s/article/2003322</a>.</li> </ul>
	<ul> <li>The M.2 SSD cannot be used to store data due to poor endurance. In write-intensive applications, the M.2 SSD will wear out in a short time.</li> <li>Use enterprise-level high endurance (HE) SSDs or HDDs for data storage.</li> </ul>
	<ul> <li>The M.2 SSD is not recommended for write-intensive service software due to poor endurance.</li> </ul>
	Do not use the M.2 SSD as the cache.
	Supports hot swap of SAS/SATA/NVMe U.2 drives.
	NOTE The NVMe drives support:
	<ul> <li>Surprise hot swap if the VMD function is enabled and the latest Intel VMD driver is installed.</li> </ul>
	Orderly hot swap if the VMD function is disabled.
•	Supports a variety of RAID controller cards. Use the Compatibility Checker to obtain information about the specific RAID controller cards supported.
	<ul> <li>The RAID controller card supports RAID configuration, RAID level migration, and drive roaming.</li> </ul>
	<ul> <li>The RAID controller card does not occupy a standard PCle slot.</li> </ul>
	For details about the RAID controller card, see V5 Server RAID Controller Card User Guide.

Component	Specifications
	Supports SAS HBA cards or SAS RAID controller card (with a 1 GB, 2 GB, or 4 GB cache) to improve storage performance and data security.  NOTE  If the BIOS is in legacy mode, the 4K drive cannot be used as the boot drive.
Network	Supports expansion capability of multiple types of networks.  • LOM
	<ul> <li>Supports two 10GE optical ports and two GE electrical ports via the NIC chip integrated on the mainboard.</li> </ul>
	<ul> <li>Supports two 10GE electrical ports and two GE electrical ports via the NIC chip integrated on the mainboard.</li> </ul>
	<ul> <li>The LOM ports support NC-SI, WOL, and PXE.</li> </ul>
	FlexIO card
	<ul> <li>Supports on-demand configuration.</li> </ul>
	<ul> <li>Supports a variety of FlexIO cards. Use the         Compatibility Checker to obtain information about         the specific FlexIO cards supported.</li> </ul>
	- When IB cards are used to build an IB network, ensure that the IPoIB modes of the IB cards at both ends of the network are the same. For details, contact technical support.
	NOTE
	The electrical ports provided by LOMs, FlexIO cards, and PCIe NICs cannot be connected to PoE devices (such as a switch with PoE enabled). Connecting such an electrical port to a PoE device may cause link communication failure or even damage the NIC.
	<ul> <li>Forcibly powering off a server will cause intermittent NC-SI disconnection and disable the WOL function of the LOM ports. To restore the NC-SI connection, refresh the iBMC WebUI.</li> </ul>

Component	Specifications
I/O expansion	10 PCle 3.0 slots:
	One slot dedicated for a screw-in RAID controller card, one dedicated for a FlexIO card, and eight for standard PCle cards.  For details, see 5.7.2 PCle Slots and 5.7.3 PCle Slot Description.
	<ul> <li>Support PCIe SSD cards to bolster I/O performance for applications such as searching, caching, and download services.</li> </ul>
	Supports GPU cards.
	When IB cards are used to build an IB network, ensure that the IPoIB modes of the IB cards at both ends of the network are the same. For details, contact technical support.
	NOTE The preceding information is for reference only. Use the Compatibility Checker to obtain specific information.
Port	Supports a variety of ports.
	Ports on the front panel:
	<ul><li>Two USB 2.0 ports</li></ul>
	<ul><li>One USB 3.0 port</li></ul>
	<ul><li>One DB15 VGA port</li></ul>
	NOTE  For the server that uses 12 x 3.5", 20 x 2.5" (8 x SAS/SATA + 12 x NVMe) or 25 x 2.5" drive configuration, the front panel provides only two USB 2.0 ports.
	Ports on the rear panel:
	<ul><li>Two USB 3.0 ports</li></ul>
	<ul><li>One DB15 VGA port</li></ul>
	<ul> <li>One RJ45 serial port</li> </ul>
	<ul> <li>One RJ45 system management port</li> </ul>
	Two GE electrical ports
	<ul> <li>Two 10GE electrical ports or 10GE optical ports</li> </ul>
	Built-in ports:
	<ul><li>One USB 3.0 port</li></ul>
	<ul><li>Two SATA ports</li></ul>
	NOTE In the 8 x 2.5" or 24 x 2.5" drive configuration, only two SATA built-in ports are provided.
	NOTE You are not advised to install the operating system on the USB storage media.

Component	Specifications
Video card	An SM750 video chip with 32 MB display memory is integrated on the mainboard. The maximum display resolution is 1920 x 1200 at 60 Hz with 16 M colors.
	NOTE
	<ul> <li>SM750 is not supported by servers running the Windows Server 2019 or Windows Server 2019 Hyper-V operating systems that are in secure boot mode.</li> </ul>
	The integrated video card can provide the maximum display resolution (1920 x 1200) only after the video card driver matching the operating system version is installed. Otherwise, only the default resolution supported by the operating system is provided.
	If the chassis provides the front and rear VGA ports but only one VGA port is connected to a monitor, the display effect may be affected.
System management	Supports UEFI.
	Supports iBMC.
	Supports NC-SI.
	Supports integration with third-party management systems.
Security feature	Power-on password
	Administrator password
	TCM (only in China)/TPM
	Secure boot
	Front bezel (optional)

## **6.2 Environmental Specifications**

Table 6-2 Environmental specifications

Category	Specifications
Temperature	Operating temperature: 5°C to 45°C (41°F to 113°F)     (ASHRAE Classes A1 to A4 compliant)
	Storage temperature (within three months): –30°C to +60°C (–22°F to +140°F)
	<ul> <li>Storage temperature (within six months): -15°C to +45°C (5°F to 113°F)</li> </ul>
	<ul> <li>Storage temperature (within one year): -10°C to +35°C (14°F to 95°F)</li> </ul>
	Maximum rate of temperature change: 20°C (36°F) per hour, 5°C (9°F) per 15 minutes
	NOTE  The highest operating temperature varies depending on the server configuration. For details, see A.3 Operating Temperature Limitations.
Relative humidity (RH,	Operating humidity: 8% to 90%
non-condensing)	Storage humidity (within three months): 8% to 85%
	Storage humidity (within six months): 8% to 80%
	Storage humidity (within one year): 20% to 75%
	Maximum change rate: 20%/h
Air volume	≥ 204 cubic feet per minute (CFM)
Operating altitude	≤3050m
	When the server configuration complies with ASHRAE Classes A1 and A2 and the altitude is above 900 m (2952.76 ft), the highest operating temperature decreases by 1°C (1.8°F) for every increase of 300 m (984.25 ft).
	When the configuration complies with ASHRAE Class A3 standards and the altitude is above 900 m (2952.76 ft.), the highest operating temperature decreases by 1°C (1.8°F) for every increase of 175 m (574.14 ft.).
	When the server configuration complies with ASHRAE Class A4 and the altitude is above 900 m (2952.76 ft), the highest operating temperature decreases by 1°C (1.8°F) for every increase of 125 m (410.1 ft).
	HDDs cannot be used at an altitude of over 3050 m (10006.44 ft).

Category	Specifications
Corrosive gaseous contaminant	Maximum corrosion product thickness growth rate:
	Copper corrosion rate test: 300 Å/month (meeting level G1 requirements of the ANSI/ISA-71.04-2013 standard on gaseous corrosion)
	Silver corrosion rate test: 200 Å/month
Particle contaminant	The equipment room environment meets the requirements of ISO 14664-1 Class 8.
	There is no explosive, conductive, magnetic, or corrosive dust in the equipment room.
	NOTE  It is recommended that the particulate pollution in the equipment room be monitored by a professional agency.
Acoustic noise	The declared A-weighted sound power levels (LWAd) and declared average bystander position A-weighted sound pressure levels (LpAm) listed are measured at 23°C (73.4°F) in accordance with ISO 7779 (ECMA 74) and reported in accordance with ISO 9296 (ECMA 109).
	• Idle:
	<ul><li>LWAd: 5.64 Bels</li></ul>
	<ul><li>– LpAm: 42.2 dBA</li></ul>
	Operating:
	<ul><li>LWAd: 6.08 Bels</li></ul>
	– LpAm: 46.8 dBA
	NOTE  The noise generated during operation varies depending on the server configuration, load, and ambient temperature.

## **◯** NOTE

SSDs and HDDs (including NL-SAS, SAS, and SATA) cannot be preserved for a long time in the power-off state. Data may be lost or faults may occur if the preservation duration exceeds the specified maximum duration. When drives are preserved under the storage temperature and humidity specified in the preceding table, the following preservation time is recommended:

- Maximum preservation duration of SSDs:
  - 12 months in power-off state without data stored
  - 3 months in power-off state with data stored
- Maximum preservation duration of HDDs:
  - 6 months in unpacked/packed and powered-off state
- The maximum preservation duration is determined according to the preservation specifications provided by drive vendors. For details, see the manuals provided by drive vendors.

## **6.3 Physical Specifications**

Table 6-3 Physical specifications

Item	Description
Dimensions (H x W x D)	3.5" drive chassis: 86.1 mm x 447 mm x 748 mm (3.39 in. x 17.60 in. x 29.45 in.)     2.5" drive chassis: 86.1 mm x 447 mm x 708 mm (3.39 in. x 17.60 in. x 27.87 in.)  Figure 6-1 Physical dimensions (example: 3.5" drive chassis)
	<ul> <li>NOTE</li> <li>See Figure 6-1 for methods in measuring physical dimensions of the chassis.</li> <li>Methods measuring 3.5" and 2.5" drive chassis are the same. The 3.5" drive chassis is used as an example.</li> </ul>

Item	Description
Installation dimension requirements	Requirements for cabinet installation:     19-inch standard cabinet compliant with the     International Electrotechnical Commission (IEC) 297     standard
	<ul><li>Cabinet width: 482.6 mm (19.00 in.)</li></ul>
	<ul> <li>Cabinet depth ≥ 1000 mm (39.37 in.)</li> </ul>
	Requirements for guide rail installation:
	<ul> <li>L-shaped guide rails: apply only to our company's cabinets.</li> </ul>
	<ul> <li>Adjustable L-shaped guide rail: apply to cabinets with a distance of 543.5 mm to 848.5 mm (21.40 in. to 33.41 in.) between the front and rear mounting bars.</li> </ul>
	<ul> <li>Ball bearing rail kit: applies to cabinets with a distance of 610 mm to 914 mm (24.02 in. to 35.98 in.) between the front and rear mounting bars.</li> </ul>
Fully equipped weight	Net weight:
	<ul> <li>Maximum weight for server with 8 x 2.5" front drives + 4 x 2.5" rear drives: 25.1 kg (55.34 lb)</li> </ul>
	<ul> <li>Maximum weight for server with 12 x 3.5" front drives + 4 x 3.5" rear drives + 4 x 2.5" rear drives:</li> <li>34.1 kg (75.18 lb)</li> </ul>
	<ul> <li>Maximum weight for server with 24 x 2.5" front drives + 4 x 2.5" rear drives: 29.4 kg (64.82 lb)</li> </ul>
	<ul> <li>Maximum weight for server with 25 x 2.5" front drives + 2 x 3.5" rear drives + 4 x 2.5" rear drives:</li> <li>30.5 kg (67.24 lb)</li> </ul>
	Packaging materials: 5 kg (11.02 lb)
Energy consumption	The power consumption parameters vary with server configurations, including the configurations complying with energy-related products (ErP) requirements. Use the <b>Power Calculator</b> to obtain specific information.

## Software and Hardware Compatibility

Use the **Compatibility Checker** to obtain information about the operating systems and hardware supported.

#### NOTICE

- If incompatible components are used, the device may be abnormal. This fault is beyond the scope of technical support and warranty.
- The performance of servers is closely related to application software, basic middleware software, and hardware. The slight differences of the application software, middleware basic software, and hardware may cause performance inconsistency between the application layer and test software layer.
  - If the customer has requirements on the performance of specific application software, contact sales personnel to apply for POC tests in the pre-sales phase to determine detailed software and hardware configurations.
  - If the customer has requirements on hardware performance consistency, specify the specific configuration requirements (for example, specific drive models, RAID controller cards, or firmware versions) in the pre-sales phase.

# 8 Safety Instructions

- 8.1 Security
- 8.2 Maintenance and Warranty

## 8.1 Security

## **General Statement**

- Comply with local laws and regulations when installing devices. These Safety Instructions are only a supplement.
- The "DANGER", "WARNING", and "CAUTION" information in this document does not represent all the safety instructions, but supplements to the safety instructions.
- Observe all safety instructions provided on the device labels when installing hardware. Follow them in conjunction with these Safety Instructions.
- Only qualified personnel are allowed to perform special tasks, such as performing high-voltage operations and driving a forklift.

## **MARNING**


If this device works in a residential environment, the wireless interference may be generated.

#### **Human Safety**

- This equipment is not suitable for use in places where children may be present.
- Only certified or authorized personnel are allowed to install the device.
- Discontinue any dangerous operations and take protective measures. Report anything that could cause personal injury or device damage to a project supervisor.
- Do not move devices or install racks and power cables in hazardous weather conditions.

- Do not carry the weight that is over the maximum load per person allowed by local laws or regulations. Before moving or installing equipment, check the maximum equipment weight and arrange required personnel.
- Wear clean protective gloves, ESD clothing, a protective hat, and protective shoes, as shown in **Figure 8-1**.

Figure 8-1 Safety work wear



 Before touching a device, wear ESD clothing and gloves (or wrist strap), and remove any conductive objects (such as watches and jewelry). Figure 8-2 shows conductive objects that must be removed before you touch a device.


Figure 8-2 Removing conductive objects



Figure 8-3 shows how to wear an ESD wrist strap.

- a. Put your hands into the ESD wrist strap.
- b. Tighten the strap buckle and ensure that the ESD wrist strap is in contact with your skin.
- c. Insert the ground terminal attached to the ESD wrist strap into the jack on the grounded rack or chassis.

Figure 8-3 Wearing an ESD wrist strap



- Exercise caution when using tools.
- If the installation position of the device is higher than the shoulders of the
  installation personnel, use a vehicle such as a lift to facilitate installation. Prevent
  the equipment from falling down and causing personal injury or damage to the
  equipment.
- The equipment is powered by high-voltage power sources. Direct or indirect contact (especially through damp objects) with high-voltage power sources may result in serious injury or death.
- Ground the equipment before powering it on. Otherwise, personal injury may be caused by high electricity leakage.
- When a ladder is used, ensure that another person holds the ladder steady to prevent accidents.
- When connecting, testing, or replacing an optical cable, do not look into the optical port without eye protection.

## **Equipment Safety**

- Use the recommended power cables at all times.
- Use power cables only for dedicated servers. Do not use them for other devices.
- Before operating equipment, wear ESD clothes and gloves to prevent electrostatic-sensitive devices from being damaged by ESD.
- When moving a device, hold the bottom of the device. Do not hold the handles of the installed modules, such as the PSUs, fan modules, drives, and the mainboard. Handle the equipment with care.
- Exercise caution when using tools that could cause personal injury.
- If the device is configured with active and standby PSUs, connect power cables
  of active and standby PSUs to different power distribution units (PDUs) to
  ensure reliable system operating.
- Ground the equipment before powering it on.

## **Transportation Precautions**

Improper transportation may damage equipment. Contact the manufacturer for precautions before attempting transportation.

Transportation precautions include but are not limited to:

 The logistics company engaged to transport the device must be reliable and comply with international standards for transporting electronics. Ensure that the equipment being transported is always kept upright. Take necessary precautions to prevent collisions, corrosion, package damage, damp conditions and pollution.

- Transport the equipment in its original packaging.
- If the original packaging is unavailable, package heavy, bulky parts (such as chassis and blades) and fragile parts (such as PCIe GPUs and SSDs) separately.

#### □ NOTE

Use **Compatibility Checker** to obtain information abut the components supported by a node or server.

Power off all devices before transportation.

## Maximum Weight Carried by a Person



To reduce the risk of personal injury, comply with local regulations with regard to the maximum weight one person is permitted to carry.

**Table 8-1** lists the maximum weight one person is permitted to carry as stipulated by a number of organizations.

Table 8-1 Maximum weight carried per person

Organization	Weight (kg/lb)
European Committee for Standardization (CEN)	25/55.13
International Organization for Standardization (ISO)	25/55.13
National Institute for Occupational Safety and Health (NIOSH)	23/50.72
Health and Safety Executive (HSE)	25/55.13

For more information about safety instructions, see **Server Safety Information**.

## 8.2 Maintenance and Warranty

For details about the maintenance policy, visit **Customer Support Service**.

For details about the warranty policy, visit **Warranty**.

## 9 System Management

The server uses the next-generation Intelligent Baseboard Management Controller (iBMC) to implement remote server management. The iBMC complies with IPMI 2.0 and provides highly reliable hardware monitoring and management.

#### **Features**

The iBMC supports the following features and protocols:

- KVM and text console redirection
- Remote virtual media
- IPMI
- SNMP
- Common information model (CIM)
- Redfish
- Browser-based login

## **Specifications**

Table 9-1 iBMC specifications

Specifications	Description
Management interface	Integrates with any standard management system through the following interfaces:
	• IPMI
	• CLI
	• HTTPS
	• SNMP
	Redfish
Fault Detection	Detects and accurately locates faults in a field replaceable unit (FRU).

Specifications	Description	
System watchdog	Supports BIOS POST, OS watchdog, and automatic system reset after fault timeout. Users can enable or disable these features individually.	
Setting of boot device	Supports out-of-band configuration for the boot device.	
Alarm management	Supports alarm management and reports alarms using the SNMP trap, SMTP, and syslog service to ensure 24/7 operating.	
Integrated virtual KVM	Provides remote maintenance measures and VNC service for troubleshooting.	
Integrated virtual media	Virtualizes local media devices, images, USB keys, and folders into media devices on a remote server, simplifying OS installation. (The virtual DVD-ROM drive supports a maximum transmission rate of 8 MB/s.)	
WebUI	Provides a user-friendly graphical user interface (GUI), which simplifies users' configuration and query operations.	
Fault reproduction	Reproduces faults to facilitate fault diagnosis.	
Screen snapshots and videos	Allows users to view screenshots and videos without login, facilitating routine preventive maintenance inspection (PMI).	
Black Box	Allows users to enable or disable the black box function and download black box data.	
DNS/LDAP	Supports domain management and directory services, which significantly simplify network and configuration management.	
Dual-image backup	Allows a boot from the backup image when the active software crashes.	
Device asset management	Provides intelligent asset management, supporting unified management and stocktaking of assets in use.	
Intelligent power management	Uses the power capping technology to increase deployment density, and uses dynamic energy saving to lower operating expenses.	
IPv6	Supports IPv6 to help build an all-IPv6 environment.	
Network Controller Sideband Interface (NC-SI)	Supports NC-SI, allowing access to the iBMC through the service network port.	

# 10 Certifications

Country/Region	Certification	Standards
Europe	WEEE	2012/19/EU
Europe	REACH	EC NO. 1907/2006
Europe	CE	Safety:
		EN 62368-1:2014+A11:2017
		EMC:
		EN 55032:2015+A11:2020
		CISPR 32:2015+A1:2019
		EN IEC 61000-3-2:2019+A1:2021
		EN 61000-3-3:2013+A1:2019
		EN 55035:2017+A11:2020
		CISPR 35:2016
		EN 55024:2010+A1:2015
		CISPR 24:2010+A1:2015
		ETSI EN 300 386 V1.6.1:2012
		ETSI EN 300 386 V2.1.1:2016
		RoHS:
		EN IEC 63000:2018
		ErP:
		Commission Regulation(EU) 424/2019
Russia	EAC&GOST	ГОСТ CISPR 32-2015
		ГОСТ CISPR 24-2013
		ГОСТ 30804 3.2-2013
		ГОСТ 30804 3.3-2013
		ГОСТ 15150-69

Country/Region	Certification	Standards
UK UK	UKCA	Standards  Safety: EN 62368-1:2014+A11:2017  EMC: EN 55032:2015+A11:2020  CISPR 32:2015+A1:2019  EN IEC 61000-3-2:2019+A1:2021  EN 61000-3-3:2013+A1:2019  EN 55035:2017+A11:2020  CISPR 35:2016  EN 55024:2010+A1:2015  CISPR 24:2010+A1:2015  ETSI EN 300 386 V1.6.1:2012  ETSI EN 300 386 V2.1.1:2016  RoHS: BS EN IEC 63000:2018  ErP:
China	ccc	Commission Regulation(EU) 424/2019  GB 17625.1-2022  GB 4943.1-2022  GB/T 9254.1-2021 (Class A)
China	RoHS	SJ/T-11364 GB/T 26572
North America	NRTL	UL 62368-1:2014 CAN/CSA-C22.2 NO.62368-1-14
US	FCC	FCC PART 15
Canada	IC	ICES-003
Japan	VCCI	VCCI 32-1
Global	СВ	IEC 62368-1:2014

# 1 1 Waste Product Recycling

If product users need product recycling service provided by xFusion after products are scrapped, contact technical support for services.




# A.1 Chassis Label

**NOTE** 

The label information and location are for reference only. For details, see the actual product.

# A.1.1 On the Front Top

Figure A-1 Chassis head label



1	Nameplate	2	Certificate
3	Quick access tag	4	SN
			NOTE For details, see A.2 Product SN.

5	Slide-out label plate	6	SN
	NOTE The label locations vary with server models or configurations. For details, see 5.1.1 Appearance.		NOTE For details, see A.2 Product SN.
7	Reserved space for custom label	8	Pressure-proof label  NOTE  This label indicates that do not place any objects on top of a rackmounted device.

# A.1.1.1 Nameplate

Figure A-2 Nameplate example




Table A-1 Nameplate description

No.	Description
1	Server Model
	For details, see <b>A.4 Nameplate</b> .
2	Device names
3	Power Supply Requirements
4	Enterprise Standard No.
5	Vendor Information
6	Authentication ID

#### A.1.1.2 Certificate

Figure A-3 Sample certificate



Table A-2 Certificate description

No.	Description
1	Order
2	No.  NOTE  For details, see Figure A-4 and Table A-3.
3	QC inspector
4	Production date
5	No. Barcode

Figure A-4 Sample certificate No.



Table A-3 Certificate No. Description

No.	Description
1	The value for this digit is <b>P</b> , which is fixed.
2	The value for this digit is <b>Z</b> , which is fixed.
3	<ul> <li>Y: indicates a server.</li> <li>B: indicates a semi-finished server.</li> <li>N: indicates a spare part.</li> </ul>

No.	Description	
4	The value is <b>0</b> . This digit is a reserved digit.	
5	Indicates the year (two digits).	
6	<ul> <li>Indicates the month (one digit).</li> <li>Digits 1 to 9 indicate January to September, respectively.</li> <li>Letters A to C indicate October to December, respectively.</li> </ul>	
7	Indicates the day (one digit).  Digits 1 to 9 indicate the 1st to 9th  Letters A to H indicate the 10th to 17th.  Letters J to N indicate the 18th to 22nd.  Letters P to Y indicate the 23rd to 31st	
8	Indicates the hour (one digit).  Digits 0 to 9 indicate 0:00 to 9:00.  Letters A to H indicate 10:00 to 17:00.  Letters J to N indicate 18:00 to 22:00.  Letters P to Q indicate 23:00 to 24:00.	
9	Indicates the serial number (two digits).	
10	Indicates the manufacturing serial number (five digits).	

### A.1.1.3 Sample Quick Access Tags

Figure A-5 Sample quick access tags





Table A-4 Quick access tab description

No.	Description
1	IP address of the iBMC management network port
2	Subnet mask of the iBMC management network port

No.	Description
3	Default iBMC user name
4	Default iBMC password
5	Default BIOS password
6	Technical support website
7	P/N Code
8	QR Code  NOTE  Scan the QR code to obtain technical support resources.

#### A.1.2 Chassis Tail Label

Figure A-6 Chassis tail label




**◯** NOTE

For details about the warning label, see **Server Safety Information**.

# A.1.3 Chassis Internal Label

Figure A-7 Chassis internal label



#### **◯** NOTE


- The quick guide is located on the inside of the chassis cover. It describes how to remove
  the mainboard components, important components of the chassis, precautions, and QR
  codes of technical resources. The pictures are for reference only. For details, see the
  actual product.
- The quick guide is optional. For details, see the actual product.

#### A.2 Product SN

The serial number (SN) on the slide-out label plate uniquely identifies a device. The SN is required when you contact technical support. **Figure A-8** and **Figure A-9** show the SN formats.

SN example 1

Figure A-8 SN example 1



• SN example 2

Figure A-9 SN example 2




Table A-5 SN example description

No.	Description
1	ESN ID (two characters), which can only be 21.
2	Material ID (eight characters), that is, the processing code.
3	Vendor code (two characters), that is, the code of the processing place.

No.	Description		
4	Year and month (two characters).		
	The first character indicates the year.		
	<ul> <li>Digits 1 to 9 indicate years 2001 to 2009, respectively.</li> </ul>		
	<ul> <li>Letters A to H indicate years 2010 to 2017, respectively.</li> </ul>		
	<ul> <li>Letters J to N indicate years 2018 to 2022, respectively.</li> </ul>		
	<ul> <li>Letters P to Y indicate years 2023 to 2032, respectively.</li> </ul>		
	NOTE The years from 2010 are represented by upper-case letters excluding I, O, and Z because the three letters are similar to the digits 1, 0, and 2.		
	The second character indicates the month.		
	<ul> <li>Digits 1 to 9 indicate January to September, respectively.</li> </ul>		
	<ul> <li>Letters A to C indicate October to December, respectively.</li> </ul>		
5	Serial number (six digits).		
6	RoHS compliance (one character). <b>Y</b> indicates RoHS compliant.		
7	Internal model (product name) of the board. The model format varies according to the actual situation.		

# **A.3 Operating Temperature Limitations**

**Table A-6** Operating temperature limitations

Configuratio n	Maximum Operating Temperature 30°C (86°F)	Maximum Operating Temperature 35°C (95°F)	Maximum Operating Temperature 40°C (104°F)	Maximum Operating Temperature 45°C (113°F)
8 x 2.5-inch drive configuration	All options supported.	<ul> <li>No support for V100, V100s, P100, A800, A100, and A40 GPU cards</li> <li>No support for the T4 GPU card</li> </ul>	<ul> <li>No support for the PCIe SSD card</li> <li>No support for the passively cooled GPU card</li> </ul>	<ul> <li>Support for Platinum 8153, Gold 6152/6140/6126/5118/5215, Silver 4216/4215/4214 and other processors under 105 W</li> <li>No support for the PCIe SSD card</li> <li>No support for the GPU card</li> <li>No support for the IB standard card and OPA standard card</li> </ul>

Configuratio n	Maximum Operating Temperature 30°C (86°F)	Maximum Operating Temperature 35°C (95°F)	Maximum Operating Temperature 40°C (104°F)	Maximum Operating Temperature 45°C (113°F)
8 x 3.5-inch drive pass- through configuration	No support for V100, V100s, P100, A800, A100, and A40 GPU cards	No support for the passively cooled GPU card	<ul> <li>No support for the PCIe SSD card</li> <li>No support for the GPU card</li> <li>No support for the rear drive</li> <li>No support for the rear drive</li> </ul>	Not supported
12 x 3.5-inch drive EXP configuration	No support for V100, V100s, P100, A800, A100, and A40 GPU cards	No support for the passively cooled GPU card	<ul> <li>No support for the PCIe SSD card</li> <li>No support for the GPU card</li> <li>No support for the rear drive</li> <li>No support for the rear drive</li> </ul>	Not supported
12 x 3.5-inch drive pass- through configuration	No support for V100, V100s, P100, A800, A100, and A40 GPU cards	No support for the passively cooled GPU card	<ul> <li>No support for the PCIe SSD card</li> <li>No support for the GPU card</li> <li>No support for the rear drive</li> <li>No support for the build-in drive</li> </ul>	Not supported

Configuratio n	Maximum Operating Temperature 30°C (86°F)	Maximum Operating Temperature 35°C (95°F)	Maximum Operating Temperature 40°C (104°F)	Maximum Operating Temperature 45°C (113°F)
20 x 2.5-inch drive configuration (8 x SAS/ SATA + 12 x NVMe drives)	<ul> <li>No support for V100, V100s, P100, A800, A100, and A40 GPU cards</li> </ul>	No support for the passively cooled GPU card	Not supported	Not supported
24 x 2.5-inch drive pass- through configuration	No support for V100, V100s, P100, A800, A100, and A40 GPU cards	No support for the passively cooled GPU card	<ul> <li>No support for the PCIe SSD card</li> <li>No support for the GPU card</li> <li>No support for the rear drive</li> <li>No support for the rear drive</li> </ul>	Not supported
24 x 2.5-inch NVMe drive configuration	No support for V100, V100s, P100, A800, A100, and A40 GPU cards	<ul> <li>No support for the rear drive</li> <li>No support for the passively cooled GPU card</li> </ul>	Not supported	Not supported
25 x 2.5-inch drive EXP configuration	No support for V100, V100s, P100, A800, A100, and A40 GPU cards	No support for the passively cooled GPU card	<ul> <li>No support for the PCIe SSD card</li> <li>No support for the GPU card</li> <li>No support for the rear drive</li> </ul>	Not supported

#### 

- When a fan is faulty:
  - The maximum operating temperature is 5°C (9°F) lower than the rated value.
  - The system performance may be affected when a GPU card is configured.
- When a P4 GPU card is configured:
  - When three or fewer cards are configured, the maximum operating temperature is 35°C (95°F).
  - When four or more cards are configured, the maximum operating temperature is 30°C (86°F).
- When deployed at an interval of at least 1U, the 8 x 3.5 models support V100, V100s, P100, A800, A100, A40, and A10 GPU cards. The maximum operating temperature supported by the fans is 30°C (86°F) when the fans are working properly.
- When the V100 GPU card is configured, the maximum operating temperature is 30°C (86°F).

# A.4 Nameplate

Certified Model	Usage Restrictions	
H22H-05	Global	
2288H V5	Global	
Note: The nameplate depends on the actual product.		

### A.5 RAS Features

The server supports a variety of Reliability, Availability, and Serviceability (RAS) features. You can configure these features for better performance.

For details about how to configure these features, see the **Server Purley Platform BIOS Parameter Reference**.

Table A-7 Supported RAS features

Module	Feature	Description
CPU	Corrected Machine Check Interrupt (CMCI)	Corrects error-triggered interrupts.
Memory	Failed DIMM Isolation	Identifies faulty DIMMs to facilitate isolation and replacement of the faulty DIMMs.
	Memory Thermal Throttling	Automatically adjusts the memory temperature to prevent the memory from being damaged due to overheat.

Module	Feature	Description
	Rank Sparing	Uses some memory ranks for backup to prevent the system from breaking down due to uncorrectable errors.
	Memory Address Parity Protection	Detects memory command and address errors.
	Memory Demand and Patrol Scrubbing	Corrects correctable errors upon detection. If these errors are not corrected in a timely manner, uncorrectable errors may occur.
	Memory Mirroring	Provides high reliability for the system via mirroring.
	Single Device Data Correction (SDDC)	Corrects single-chip multi-bit errors to improve memory reliability.
	Device Tagging	Degrades and rectifies memory faults to improve memory availability.
	Data Scrambling	Optimizes data flow distribution to reduce the error probability and improve memory data flow reliability and address error detection.
PCle	PCIe Advanced Error Reporting	Provides a PCIe advanced error reporting mechanism to improve server serviceability.
UPI	Intel UPI Link Level Retry	Provides a retry mechanism to improve the reliability of UPI links.
	Intel UPI Protocol Protection via CRC	Provides cyclic redundancy check (CRC) protection for UPI data packets to improve system reliability.
System	Core Disable For FRB (Fault Resilient Boot)	Isolates a faulty CPU core during startup to improve system reliability and availability.
	Corrupt Data Containment Mode	Marks the memory storage unit when a data error occurs to limit the impact on the running program and improve system reliability.
	Socket disable for FRB (Fault Resilient Boot)	Isolates a faulty socket during the BIOS startup process to improve system reliability.

Module	Feature	Description
	Architected Error Records	With the features such as eMCA, the BIOS collects error information recorded in hardware registers in compliance with UEFI specifications, notifies the OS through the APEI interface of the ACPI, and locates the error unit, improving system availability.
	Error Injection Support	Implements fault injection to verify RAS features.
	Machine Check Architecture (MCA)	Provides a software repair function to rectify uncorrectable errors to improve system availability.
	Enhanced Machine Check Architecture (eMCA): Gen2	Improves system availability.
	OOB access to MCA registers	The out-of-band system can access MCA registers through the PECI. When a fatal error occurs in the system, the out-of-band system can collect onsite data to facilitate subsequent fault analysis and locating and improve system serviceability.
	BIOS Abstraction Layer for Error Handling	The BIOS processes errors and reports error information to the OS based on specifications, improving system serviceability.
	BIOS-based Predictive Failure Analysis (PFA)	The OS takes the lead. The BIOS provides information about physical memory error units. The OS tracks, predicts, and handles the errors.

# A.6 Sensor List

Sensor	Description	Component
Inlet Temp	Air inlet temperature	Left mounting ear
Outlet Temp	Air outlet temperature	Mainboard
PCH Temp	PCH bridge temperature	Mainboard
CPUN Core Rem	CPU core temperature	CPUN  N indicates the CPU number. The value ranges from 1 to 2.

Sensor	Description	Component
CPUN DTS	CPU DTS value	CPUN N indicates the CPU number. The value ranges from 1 to 2.
CPUN Margin	CPU Margin	CPUN  N indicates the CPU number. The value ranges from 1 to 2.
CPUN VDDQ Temp	CPU VDDQ temperature	Mainboard  N indicates the CPU number. The value ranges from 1 to 2.
CPUN VRD Temp	CPU VRD temperature	Mainboard  N indicates the CPU number. The value ranges from 1 to 2.
CPUN MEM Temp	CPU DIMM temperature	DIMMs of CPU N  N indicates the CPU number. The value ranges from 1 to 2.
SYS 3.3V	Mainboard 3.3 V voltage	Mainboard
SYS 5V	Mainboard 5.0 V voltage	Mainboard
SYS 12V_1	Mainboard 12.0 V voltage	Mainboard
SYS 12V_2	Mainboard 12.0 V voltage	Mainboard
CPUN VCore	1.8 V CPU voltage	Mainboard  N indicates the CPU number. The value ranges from 1 to 2.
CPUN DDR VDDQ	1.2 V DIMM voltage	Mainboard  N indicates the CPU number. The value ranges from 1 to 2.
CPUN DDR VDDQ2	1.2 V DIMM voltage	Mainboard  N indicates the CPU number. The value ranges from 1 to 2.

Sensor	Description	Component
CPUN VSA	CPU VSA voltage	Mainboard  N indicates the CPU number. The value ranges from 1 to 2.
CPUN VCCIO	CPU VCCIO voltage	Mainboard  N indicates the CPU number. The value ranges from 1 to 2.
CPUN VMCP	CPU VMCP voltage	Mainboard  N indicates the CPU number. The value ranges from 1 to 2.
PCH VPVNN	PCH VPVNN voltage	Mainboard
PCH PRIM 1V05	PCH PRIM voltage	Mainboard
CPUN VCCP	CPU VCCP voltage	Mainboard  N indicates the CPU number. The value ranges from 1 to 2.
CPUN DDR VPP1	VPP_ABC voltage	Mainboard  N indicates the CPU number. The value ranges from 1 to 2.
CPUN DDR VPP2	VPP_DEF voltage	Mainboard  N indicates the CPU number. The value ranges from 1 to 2.
FANN Speed	Fan speed sensor	Fan module <i>N N</i> indicates the fan module number. The value ranges from <b>1</b> to <b>4</b> .
Power	Server input power	PSU
PSN VIN	PSUN input voltage	PSUN N indicates the PSU number. The value is 1 or 2.
Disks Temp	Drive maximum temperature	Drive

Sensor	Description	Component
PowerN	PSU input power	PSUN
		N indicates the PSU number. The value is <b>1</b> or <b>2</b> .
PCH Status	PCH chip fault diagnosis health status	Mainboard
CPUN QPI Link	CPU QPI link fault	Mainboard or CPU <i>N</i>
	diagnosis health status	N indicates the CPU number. The value ranges from 1 to 2.
CPUN Prochot	CPU Prochot	CPUN
		N indicates the CPU number. The value ranges from <b>1</b> to <b>2</b> .
CPUN Status	CPU status	CPUN
		N indicates the CPU number. The value ranges from <b>1</b> to <b>2</b> .
CPUN Memory	CPU memory status	DIMMs of CPU N
		N indicates the CPU number. The value ranges from <b>1</b> to <b>2</b> .
FANN Status	Fan status	Fan module <i>N</i>
		N indicates the fan module number. The value ranges from <b>1</b> to <b>4</b> .
DIMMN	DIMM status	DIMMN
		N indicates the DIMM slot number.
RTC Battery	RTC battery status. An alarm is generated when the voltage is lower than 1 V.	RTC battery
PCIE Status	PCIe status	PCle card
Power Button	Power button pressed state	Mainboard and power button
Watchdog2	Watchdog timer	Mainboard
Mngmnt Health	Management subsystem health status	Management module

Sensor	Description	Component
UID Button	UID button status	Mainboard
PwrOk Sig. Drop	Voltage dip status	Mainboard
PwrOn TimeOut	Power-on timeout	Mainboard
PwrCap Status	Power capping status	Mainboard
HDD Backplane	Entity presence	Drive backplane
HDD BP Status	Drive backplane health status	Drive backplane
Riser <i>N</i> Card	Entity presence	Riser card <i>N N</i> indicates the riser card slot number. The value ranges from <b>1</b> to <b>3</b> .
SAS Cable	Entity presence	SAS High-speed cable
FANN R Presence	Fan presence	Fan module <i>N N</i> indicates the fan module number. The value ranges from <b>1</b> to <b>4</b> .
RAID Presence	RAID controller card presence	RAID controller card
LCD Status	LCD health status	LCD
LCD Presence	LCD presence	LCD
PS Redundancy	Redundancy failure due to PSU removal	PSU
NIC# Status	NIC fault diagnosis health status	LOM port
Port# Link Down	Network port link state	LOM port
PSN Status	PSU status	PSUN N indicates the PSU number. The value is 1 or 2.
PSN Fan Status	PSU fan status	PSUN N indicates the PSU number. The value is 1 or 2.
PSN Temp Status	PSU presence	PSUN N indicates the PSU number. The value is 1 or 2.

Sensor	Description	Component
DISKN	Drive status	Drive N N indicates the drive slot number. The value ranges from 0 to 24 or from 36 to 47.
LOM P1 Link Down	LOM	LOM
LOM P2 Link Down	LOM	LOM
LOM P3 Link Down	LOM	LOM
LOM P4 Link Down	LOM	LOM
PCIe RAID\$ Temp	PCIe RAID controller card temperature	PCIe RAID controller card
M2 Temp(PCIe\$)	Maximum temperature of all M.2 drives of the RAID controller card	PCIe RAID controller card
RAID Temp	RAID controller card temperature	RAID controller card
RAID Status	RAID controller card health status	RAID controller card
RAID PCIE ERR	RAID controller card fault diagnosis health status	RAID controller card
IB\$ TEMP	IB adapter temperature	IB card
PCIe\$ OP Temp	PCIe card optical module temperature	PCle card
PCIe NIC\$ Temp	PCIe card chip temperature	PCle card
PCIe FC\$ Temp	PCIe card chip temperature	PCle card
RAID Card BBU	RAID controller card BBU	BBU supercapacitor of LSI SAS3106 RAID controller card
SM380 Temp	25GENIC chip temperature	PCle card
PCIe\$ NIC Temp	PCle card chip temperature	PCle card
PS\$ Inlet Temp	PSU air inlet temperature	PSU
NIC\$ Presence	LOM presence	FlexIO

Sensor	Description	Component
CPUN AEP Temp	CPU DCPMM	DCPMMs of CPUN
	temperature	N indicates the CPU number. The value is <b>1</b> or <b>2</b> .
FPGA# Temp	FPGA card temperature	PCle card
FPGA# EnvTemp	FPGA card operating temperature	PCle card
FPGA# DDR Temp	FPGA card memory temperature	PCle card
FPGA# Power	FPGA card power	PCle card
FPGA# OP Temp	FPGA card optical module temperature	PCle card
GPUN Temp	GPU temperature	GPU cards
		N indicates the component number.

# **B** Glossary

# **B.1 A-E**

Ε

ejector lever	A part on the panel of a device used to facilitate installation or removal of the device.
Ethernet	A baseband local area network (LAN) architecture developed by Xerox Corporation by partnering with Intel and DEC. Ethernet uses the Carrier Sense Multiple Access/Collision Detection (CSMA/CD) access method and allows data transfer over various cables at 10 Mbit/s. The Ethernet specification is the basis for the IEEE 802.3 standard.

# **B.2 F-J**

G

media Ethernet standards. It is compatible with 10M and 100M Ethernet and complies with IEEE 802.3z standards.
----------------------------------------------------------------------------------------------------------------

Н

-	Replacing or adding components without stopping or
	shutting down the system.

# **B.3 K-O**

K

KVM	A hardware device that provides public keyboard, video
	and mouse (KVM).

# **B.4 P-T**

Ρ

panel	An external component (including but not limited to ejector levers, indicators, and ports) on the front or rear of the server. It seals the front and rear of the chassis to ensure optimal ventilation and electromagnetic compatibility (EMC).
Peripheral Component Interconnect Express (PCIe)	A computer bus PCI, which uses the existing PCI programming concepts and communication standards, but builds a faster serial communication system. Intel is the main sponsor for PCIe. PCIe is used only for internal interconnection. A PCI system can be transformed to a PCIe one by modifying the physical layer instead of software. PCIe delivers a faster speed and can replace almost all AGP and PCI buses.

R

redundancy	A mechanism that allows a backup device to automatically take over services from a faulty device to ensure uninterrupted running of the system.
redundant array of independent disks (RAID)	A storage technology that combines multiple physical drives into a logical unit for the purposes of data redundancy and performance improvement.

S

server	A special computer that provides services for clients over a network.
system event log (SEL)	Event records stored in the system used for subsequent fault diagnosis and system recovery.

# **B.5 U-Z**

U

U	A unit defined in International Electrotechnical Commission (IEC) 60297-1 to measure the height of a cabinet or chassis. 1 U = 44.45 mm
UltraPath Interconnect (UPI)	A point-to-point processor interconnect developed by Intel.

# C Acronyms and Abbreviations

### **C.1 A-E**

Α

AC	alternating current
AES	Advanced Encryption Standard New Instruction Set
ARP	Address Resolution Protocol
AVX	Advanced Vector Extensions

В

BBU	backup battery unit
BIOS	Basic Input/Output System

C

CD	calendar day
CE	Conformite Europeenne
CIM	Common Information Model
CLI	command-line interface

#### D

DC	direct current
DCPMM	DC persistent memory module
DDR3	Double Data Rate 3
DDR4	Double Data Rate 4
DDDC	double device data correction
DEMT	Dynamic Energy Management Technology
DIMM	dual in-line memory module
DRAM	dynamic random-access memory
DVD	digital video disc

# Ε

ECC	error checking and correcting
ECMA	European Computer Manufacturer Association
EDB	Execute Disable Bit
EN	European Efficiency
ERP	enterprise resource planning
ETS	European Telecommunication Standards

# C.2 F-J

# F

FB-DIMM	Fully Buffered DIMM
FC	Fiber Channel
FCC	Federal Communications Commission
FCoE	Fibre Channel over Ethernet
FTP	File Transfer Protocol

#### G

GE	Gigabit Ethernet
GPIO	General Purpose Input/Output
GPU	graphics processing unit

#### Н

НА	high availability
HDD	hard disk drive
HPC	high-performance computing
НТТР	Hypertext Transfer Protocol
HTTPS	Hypertext Transfer Protocol Secure

I

iBMC	intelligent baseboard management controller
IC	Industry Canada
ICMP	Internet Control Message Protocol
IDC	Internet Data Center
IEC	International Electrotechnical Commission
IEEE	Institute of Electrical and Electronics Engineers
IGMP	Internet Group Message Protocol
IOPS	input/output operations per second
IP	Internet Protocol
IPC	intelligent power capability
IPMB	Intelligent Platform Management Bus
IPMI	Intelligent Platform Management Interface

# C.3 K-O

K

KVM	keyboard, video, and mouse
-----	----------------------------

L

LC	Lucent connector
LRDIMM	load-reduced dual in-line memory module
LED	light emitting diode
LOM	LAN on motherboard

M

MAC	media access control
ммс	module management controller

Ν

NBD	next business day
NC-SI	Network Controller Sideband Interface

# **C.4 P-T**

Ρ

PCIe	Peripheral Component Interconnect Express
PDU	power distribution unit
PHY	physical layer
PMBUS	power management bus
РОК	power OK
PWM	pulse-width modulation

PXE	Preboot Execution Environment
-----	-------------------------------

# Q

QPI	Quick Path Interconnect	
-----	-------------------------	--

# R

RAID	redundant array of independent disks
RAS	reliability, availability and serviceability
RDIMM	registered dual in-line memory module
REACH	Registration Evaluation and Authorization of Chemicals
RJ45	registered jack 45
RoHS	Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment

#### S

SAS	Serial Attached Small Computer System Interface
SATA	Serial Advanced Technology Attachment
SCM	supply chain management
SDDC	single device data correction
SERDES	serializer/deserializer
SGMII	serial gigabit media independent interface
SMI	serial management interface
SMTP	Simple Mail Transfer Protocol
SNMP	Simple Network Management Protocol
SOL	serial over LAN
SONCAP	Standards Organization of Nigeria-Conformity Assessment Program
SSD	solid-state drive
SSE	Streaming SIMD Extensions

Т

TACH	tachometer signal
ТВТ	Turbo Boost Technology
TCG	Trusted Computing Group
TCM	trusted cryptography module
тсо	total cost of ownership
TDP	thermal design power
TELNET	Telecommunication Network Protocol
TET	Trusted Execution Technology
TFM	TransFlash module
TFTP	Trivial File Transfer Protocol
TOE	TCP offload engine
ТРМ	trusted platform module

# C.5 U-Z

U

UDIMM	unbuffered dual in-line memory module
UEFI	Unified Extensible Firmware Interface
UID	unit identification light
UL	Underwriter Laboratories Inc.
USB	Universal Serial Bus

V

VCCI	Voluntary Control Council for Interference by Information Technology Equipment
VGA	Video Graphics Array
VLAN	virtual local area network
VRD	voltage regulator-down

#### W

WEEE	waste electrical and electronic equipment
WSMAN	Web Service Management